

## W0163 - DIY INSTRUCTIONS

1. Remove the fittings from the wall
2. Once the fitting is removed, you will notice a circular diffuser (see image below with red arrow pointing at diffuser), this will need to be removed. This is glued within the recess so you will need to pinch the diffuser towards the frame where the LED tape is mounted. You will have to pinch around the diffuser until the diffuser is loose and can come off. (**Warning: this will chip some of the surrounding plasterboard off, but it will not be visible when mounted back on wall**).



3. Once diffuser is removed, you will be required to produce a few layers of thick white paint in the recess where the diffuser was sitting in. (This is what was causing the light bleed). The paint we have used is Dulux Trade – Vinyl Matt Pure brilliant white.

Once painted in the groove, please let this dry before putting back on the diffuser and test afterwards to see if enough layers of paint has been applied.

4. Once enough layers have been applied, you should end up with the finish below and eliminating the bleeding light effect.

