



Installation Instruction

1. Cut off the power supply. Punch the hole according to the support position at the installation position, and then install the expansion screw.
2. Secure mounting bracket in installation position with self-tapping screws.
3. Connect the wires correctly.
4. Screw the lamp housing onto the mounting bracket.
5. Connect power supply.

