

# OPERATING MANUAL

Warning: In order to install the lamps correctly, read this short manual carefully and keep it accessible for further reference!

## I .Main structure and scope of application

The lamp housing is made of pure aluminum. The surface is coated by electrostatic painting. It has the characteristics of waterproof, dust proof and novel structure.

It mainly suitable for lighting in places such as outdoor landscape, wind and rain corridor etc.

## II .Main structural parameters

Item No.	Rated voltage V	Power rating W	LED quantity	IP class	protection level
LEDHOODWALL B/WW	12VAC/DC	5W	1 LED	IP65	CLASSIII
LEDHOODWALL B/NW	12VAC/DC	5W	1 LED	IP65	CLASSIII

## III. Installation requirements and maintenance

1. sort out all kinds of parts and accessories used for this lamps.
2. Switch off the mains before doing any works!

## IV. Installation

1. Fix the plastic dowels(1) to a wall, then screw the base to the wall
2. Make sure the wiring and base are securely installed, then adjust the lamp body to the right angle
3. Installation is complete, connect power supply and turn the light on

## V . Attention

1. Installation, mounting or works on the electrical connection may only be carried out by an approved electrician.
2. If the housing of the product is damaged, the product shall not be used as a substandard product.

