



Table or floor dimmer

General characteristics

- Universal light dimmer;
- Installation along cable;
- Equipped with night light;
- Fuse incorporated;
- Power: 60÷450W;
- Voltage: 120V 60Hz;
- Night Light;

Instructions for use

Use the ON/OFF switch to turn one lamp on and off. To regulate light intensity use slider. When dimmer is at minimum level, the light is automatically switched off.

Note

Do not use with lamps already supplied with a dimmer. Unplug lamp before replacing fuse.
 Replace with fuse type GMC-6 (Rated 6A, 125V).

Installation and use

Connect dimmer to cable supplied with lamp. Open terminal cover, cable as indicated in Fig. 2 using exclusively Nos. 16 and 18 AWG types SPT-1 and SPT-1-1/2 and SPT-2 wire. Respecting safety norms (earth wire must be at least 8 mm longer than the other wires). Tighten cable clamps, close terminal cover and tighten screws accurately and place rubber pads on bottom part of dimmer. Keep dimmer away from direct sources of heat.

Respect C.E.I. norms for installation, following connection diagrams carefully. Tighten dimmer screws on terminal block. Every dimmer is subject to quality control and L.C. Relco guarantees correct functioning providing that installation norms are carefully respected.

Warranty

24 months from date shown on model. Warranty is extended for another 6 months to compensate for average stock time. Warranty no longer applies in the case of improper use, tampering or deletion of date.

Fig. 1




Fig. 2

