Garden light

User Manual

Thanks for your purchashing, please read this manual carefully before operating the system, it gives you general information for your safety and better operation.

Inspection

Check for the contents in the package refers to the following list:

1.IP65 water-proof and dust-proof light:1

2.Adaptor:1

3. Power cord: 1 5. Groud stake:1

4. Junction :1 6. Remote control : 1

7. Screws: 1

8. User Manual:1

Safety Attention

- Better to work 6 hours then cool it down with 30 minutes, it will
 save the lifetime of lighting source.
- ** Laser is ClassII, the power of each laser point is not more than
 1mW , no harmful to human body and eyes.
- ** This product is mainly used for outdoor with waterproof Ip65.
 It has excellent radiating ease put it far way from the flammable obejects or liquids.
- Please use our own power adaptor to support the light. If you need to change a new adaptor please check the parameter of our adaptor and buy a new One. If you need more longer power cable, please use legal cable with enough diameter and control the length or it will give more higher load to the adapter.
- When connecting the cable to the plug adapter, please make sure the 2 pin plug is the right way round ,the "Flat" and "Keyway" need to match or there will be no contact.




Remote Control Instructions

- 1.Please pull the plastic sheet out which at the bottom of the Remote firstly, when you start to use the Remote. And pls put it back into the same place if you don't use it for a long time whi can save the power. The effective receiving distance of infrared remote is about 7 meters. The effective receiving distance radio frequency remote is about 20 meters
- 2. (b) Turn on/off.
- 3. (Flash) There are two options: Strobe/No strobe
- 4. **R G B** is the buttons to change the color.
 - R Control red lighting ON/OFF;
 - © Control green lighting ON/OFF;
 - B Control blue lighting ON/OFF;
- 5. Switch Auto color-changing mode/Manual mode.
- 6. (+) Is for moving light, there are three options: Slow, fast, static.
 - Control slow and static; + control fast
- 7. If you need to use timer, press the Light strobe two times to sure it has accepted signal. you can freely control timer(press 2) 4 6 8 hours ON) If you had choose 2 hours ON but want to change 4 hours on, Just directly press 4


If you want to cancel the timer, press the **(M)** Light strobe two times to sure it has accepted signal.

Eg:choose 2 hour, means OFF after 2 hour ON, Will trun on the light automatically after 22 hours, no need operate recycling.

Installation Steps



Control Mode




Installation

- 1. Firstly, be sure that the using voltage is match with the voltage marked on the base of the laser lighting;
- 2. Fix the laser and adjust the angle of the laser light to your need.

 Don't stare into the beam or view with optical instrument
- 3.Be sure that there is no flammable or explosive subject nearby. The least distance is 0.5 meters.
- 4.The laser lighting should be fixed by inserting into soil or attached to trees etc;
- 5. It is essential to be earthed well for the stake of safety.
- Adapter to be installed indoors or an outdoor waterproof socket.





MADE IN CHINA