

LED SERIES WIRING DIAGRAM for 350mA LEDs

WARNING

All the 350mA drivers must be wired in series as shown in the diagram. If the LEDs are not wired correctly it will result in irreparable damage to the LEDs and LED Drivers. Incorrect wiring will invalidate your warranty.

WIRING INFORMATION

The reason that these LEDs must be wired in series is simple. When you wire in series you achieve a constant current for all components in that circuit. All the LEDs marked with the 'S' symbol require a constant current to function correctly. When the LEDs are wired in series they only require a small voltage, normally between 2-4 volts. No series LED has the same voltage. The voltage vary from LED to LED.

