



Switch Catalogue

Contents

Trimless Flat Plate Range

The Trimless Range is a high quality range without any plastic trim surroundings the switches. The switch modules are detachable and the plates are made from 1mm thick brass with square corners. This enables the plate to be finished in stainless or polished nickel if desired. The product is a grid system, enabling the plate to be fitted after decorating. The screws are an attractive flush hexagonal design. The switches require a 35mm back box.



Antique Silver : Page 1 - 2




Satin Nickel : Page 3 - 4



Polished Nickel : Page 5 - 6



Polished Brass : Page 7 - 8



Georgian Brass : Page 9 - 10

Classic Flat Plate Range

The Classic Flat Plate Range is high quality range, available in a large variety of finishes. The Wandsworth inserts are detachable, high quality and hard wearing. The plate is 1mm thick with square corners. The switches require a 35mm back box.



Primed White : Page 11 - 12



Satin Steel : Page 13 - 14



Polished Steel : Page 15 - 16



Polished Brass : Page 17 - 18



Satin Brass : Page 19 - 20



Clear Perspex : Page 21 - 22



Antique Bronze : Page 23 - 24

Specialist Range

The Specialist Range is a high end range of switches in a variety of styles. The ranges are designed to give an individual original look. The Wandsworth inserts are detachable, high quality and hard wearing. The switches require a 35mm back box.




Nautical : Page 25 - 26



Midas : Page 27 - 28



Monaco : Page 29 - 30




Chocolate Brown Screwless :
Page 31 - 32

Aluminium Range

The Aluminium Ranges are manufactured from aluminium with a square flat plate 1mm thick design to fit flush against the wall. The switches come with fixed modules and are incredibly simple to fit. The switches require a 35mm back box.



Silver : Page 33 - 34



Black : Page 35 - 36



Satin White : Page 37 - 38



Pink : Page 39 - 40



Lime : Page 41 - 42

Solowood Range & Asbury Range

The Solowood & Asbury Range are designed to fit in with wooden interiors and features. They come in a variety of finishes to integrate best with the decor. The switches come with fixed modules and are incredibly simple to fit.



Solowood : Page 43 - 44



Asbury Wood : Page 45 - 46

Contents

Elements Range

The Elements Flat Plate Range is made from a special hand beaten flat plate giving an appearance of a hammerite finish. This product comes in magnesium and copper finishes. The switches come with fixed modules and are incredibly simple to fit. The switches require a 35mm back box.



Copper : Page 47 - 48




Magnesium : Page 47 - 48

Quarry Range

The Quarry Raised Plate Range is made from a strong and elegant material with the look and feel of natural stone. The switches come with fixed modules and are incredibly simple to fit. The switches require a 35mm back box.



Black Pearl : Page 49 - 50



Grey Sand : Page 49 - 50



Ivory White : Page 49 - 50

Accord Raised Plate Range

The accord range is designed to fit 25mm boxes and gives the appearance of a flat plate design with an economy price.



Polished Steel : Page 51 - 52



Satin Steel : Page 53 - 54

Sleek Raised Plate Range

The Sleek Raised Plate Range is an ideal choice for modern interiors. Sleek and modern with a depth from the wall of only 6mm and bevelled edges to give an almost timeless elegance. Practical and stylish with clearly marked colour coded, in-line terminals offering effortless installation.



White Plastic : Page 55 - 56

Outdoor Range

The Outdoor Range is manufactured from tough, durable thermoplastic. It is intended for use in an outdoor environment, or one in which the protection provided by the range is required. Rated at IP66, for protection against water and dust.



Thermoplastic : Page 57 - 58

Modules & Accessories

.....

Floor Boxes : Page 59

.....

Switch Modules : Page 60

.....

Specials : Page 61 - 62

.....

Surfaced Pattress Boxes : Page 63

.....

Euro Plates : Page 64 - 66

.....

Euro & Grid Modules : Page 67 - 70

.....

Pop Up Socket : Page 71

.....

PIR Sensor Switches : Page 72

.....

Table Lamp Switches & Dimmers : Page 73

.....


Door Switches : Page 74

.....

Special Cable : Page 75

.....

Lamp Holders & Accessories : Page 76 - 78



Trimless Flat Plate - antique silver



Rocker Switches

MRTASRSW1	1 gang 20 amp 2 way
MRTASRSW1 INT	1 gang 20 amp intermediate
MRTASRSW1 DP	1 gang 20 amp double pole
MRTASRSW2	2 gang 20 amp 2 way
MRTASRSW2 INT	2 gang 20 amp intermediate
MRTASRSW3	3 gang 20 amp 2 way
MRTASRSW3 2G PL	3 gang 20 amp 2 way double plate
MRTASRSW4	4 gang 20 amp 2 way
MRTASARSW1	1 gang architrave 2 way
MRTASARSW2	2 gang architrave 2 way



Dimmer Switches

MRTASDSW1	1 gang 400 watt 2 way
MRTASDSW1 DBL PL	1 gang 400 watt 2 way double plate
MRTASDSW1 630W	1 gang 630 watt 2 way
MRTASDSW1 1000W	1 gang 1000 watt 2 way
MRTASDSW2	2 gang 400 watt 2 way
MRTASDSW2 DBL PL	2 gang 400 watt 2 way double plate
MRTASDSW3	3 gang 400 watt 2 way
MRTASDSW4	4 gang 400 watt 2 way
MRTASADSW1	1 gang 250 watt architrave

Dolly Switches

MRTASTSW1	1 gang 20 amp 2 way
MRTASTSW1 INT	1 gang 20amp intermediate
MRTASTSW1 DP	1 gang 20 amp 2 way double plate
MRTASTSW2	2 gang 20 amp 2 way
MRTASTSW3	3 gang 20 amp 2 way
MRTASTSW4	4 gang 20 amp 2 way



Switches

MRTASCWSW1	1 gang 45 amp cooker
MRTASCWSW1 SML	1 gang 45 amp cooker (single plate)
MRTASCWSW1+SSO	1 gang 50 amp cooker with switch socket outlet
MRTASFAN1	1 gang fan isolator switch
MRTASPSW1	1 gang ceiling pull



Sockets

MRTASSK1	1 gang 13 amp switched
MRTASSK2	2 gang 13 amp switched
MRTASUSK1	1 gang 5 amp unswitched socket
MRTASUSK2	2 gang 5 amp unswitched socket
MRTASFO1	1 gang flex outlet
MRTASSF1	1 gang 13 amp switched fuse spur
MRTASSFC1	1 gang 13 amp switched fuse cord spur
MRTASSFNC1	1 gang 13 amp switched fuse neon cord spur
MRTASSFN1	1 gang 13 amp switched fuse neon spur
MRTASSH1	1 gang shaver socket
MRTASFSK1	1 gang 13 amp unswitched floor socket
MRTASFUSK1	1 gang 5 amp unswitched floor socket
MRTASFSK2	2 gang 13 amp unswitched floor socket
MRTASFUSK1 2A	1 gang 2 amp unswitched floor socket



Communication & AV Sockets

MRTASJM1	1 gang telephone jackline master
MRTASJM2	2 gang telephone jackline master
MRTASJS1	1 gang telephone jackline slave
MRTASJS2	2 gang telephone jackline slave
MRTASRJ451	1 gang RJ45 cat 5 socket
MRTASRJ452	2 gang RJ45 cat 5 socket
MRTASISDN1	1 gang ISDN socket
MRTASTV1	1 gang television co-axial
MRTASTV2	2 gang television co-axial
MRTASTVSAT1	1 gang television and satellite socket
MRTASSAT1	1 gang satellite socket
MRTASSAT2	2 gang satellite socket
MRTASSP1	1 gang speaker socket
MRTASSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRTASTRIPLEX	1 gang TV/FM/SAT



Plates

MRTASBP1	1 gang single blank plate
MRTASBP2	2 gang double blank plate
MRTASEUR1	1 gang single euro plate
MRTASEUR2	2 gang single euro plate
MRTASEUR4	4 gang double euro plate
MRTASEUR8	8 gang double euro plate
MRTASBRUSH1	1 gang single brush plate 2 slots
MRTASBRUSH2	2 gang double brush plate 4 slots

Trimless Flat Plate Range





Trimless Flat Plate - satin nickel



Rocker Switches

MRTSNRSW1	1 gang 20 amp 2 way
MRTSNRSW1 INT	1 gang 20 amp intermediate
MRTSNRSW1 DP	1 gang 20 amp double pole
MRTSNRSW2	2 gang 20 amp 2 way
MRTSNRSW2 INT	2 gang 20 amp intermediate
MRTSNRSW3	3 gang 20 amp 2 way
MRTSNRSW3 2G PL	3 gang 20 amp 2 way double plate
MRTSNRSW4	4 gang 20 amp 2 way
MRTSNARSW1	1 gang architrave 2 way
MRTSNARSW2	2 gang architrave 2 way



Dimmer Switches

MRTSNDW1	1 gang 400 watt 2 way
MRTSNDW1 DBL PL	1 gang 400 watt 2 way double plate
MRTSNDW1 630W	1 gang 630 watt 2 way
MRTSNDW1 1000W	1 gang 1000 watt 2 way
MRTSNDW2	2 gang 400 watt 2 way
MRTSNDW2 DBL PL	2 gang 400 watt 2 way double plate
MRTSNDW3	3 gang 400 watt 2 way
MRTSNDW4	4 gang 400 watt 2 way
MRTSNADSW1	1 gang 250 watt architrave



Dolly Switches

MRTSNTSW1	1 gang 20 amp 2 way
MRTSNTSW1 INT	1 gang 20amp intermediate
MRTSNTSW1 DP	1 gang 20 amp 2 way double plate
MRTSNTSW2	2 gang 20 amp 2 way
MRTSNTSW3	3 gang 20 amp 2 way
MRTSNTSW4	4 gang 20 amp 2 way



Switches

MRTSNCW1	1 gang 50 amp cooker
MRTSNCW1 SML	1 gang 45 amp cooker (single plate)
MRTSNCW1+SSO	1 gang 50 amp cooker with switch socket outlet
MRTSNFAN1	1 gang fan isolator switch
MRTSNPSW1	1 gang ceiling pull



Sockets

MRTSNSK1	1 gang 13 amp switched
MRTSNSK2	2 gang 13 amp switched
MRTSNUSK1	1 gang 5 amp unswitched socket
MRTSNUSK2	2 gang 5 amp unswitched socket
MRTSNFO1	1 gang flex outlet
MRTSNSF1	1 gang 13 amp switched fuse spur
MRTSNSFC1	1 gang 13 amp switched fuse cord spur
MRTSNSFNC1	1 gang 13 amp switched fuse neon cord spur
MRTSNSFN1	1 gang 13 amp switched fuse neon spur
MRTSNSH1	1 gang shaver socket
MRTSNFSK1	1 gang 13 amp unswitched floor socket
MRTSNFUSK1	1 gang 5 amp unswitched floor socket
MRTSNFSK2	2 gang 13 amp unswitched floor socket
MRTSNFUSK1 2A	1 gang 2 amp unswitched floor socket



Communication & AV Sockets

MRTSNJM1	1 gang telephone jackline master
MRTSNJM2	2 gang telephone jackline master
MRTSNJS1	1 gang telephone jackline slave
MRTSNJS2	2 gang telephone jackline slave
MRTSNRJ451	1 gang RJ45 cat 5 socket
MRTSNRJ452	2 gang RJ45 cat 5 socket
MRTSNISDN1	1 gang ISDN socket
MRTSNTV1	1 gang television co-axial
MRTSNTV2	2 gang television co-axial
MRTSNTVSAT1	1 gang television and satellite socket
MRTSNSAT1	1 gang satellite socket
MRTSNSAT2	2 gang satellite socket
MRTSNSP1	1 gang speaker socket
MRTSNSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRTSNTRIPLEX	1 gang TV/FM/SAT



Plates

MRTSNBP1	1 gang single blank plate
MRTSNBP2	2 gang double blank plate
MRTSNEUR1	1 gang single euro plate
MRTSNEUR2	2 gang single euro plate
MRTSNEUR4	4 gang double euro plate
MRTSNEUR8	8 gang double euro plate
MRTSNBRUSH1	1 gang single brush plate 2 slots
MRTSNBRUSH2	2 gang double brush plate 4 slots

Trimless Flat Plate Range





Trimless Flat Plate - polished nickel



Rocker Switches

MRTPNRSW1	1 gang 20 amp 2 way
MRTPNRSW1 INT	1 gang 20 amp intermediate
MRTPNRSW1 DP	1 gang 20 amp double pole
MRTPNRSW2	2 gang 20 amp 2 way
MRTPNRSW2 INT	2 gang 20 amp intermediate
MRTPNRSW3	3 gang 20 amp 2 way
MRTPNRSW3 2G PL	3 gang 20 amp 2 way double plate
MRTPNRSW4	4 gang 20 amp 2 way
MRTPNARSW1	1 gang architrave 2 way
MRTPNARSW2	2 gang architrave 2 way



Sockets

MRTPNNSK1	1 gang 13 amp switched
MRTPNNSK2	2 gang 13 amp switched
MRTPNUSK1	1 gang 5 amp unswitched socket
MRTPNUSK2	2 gang 5 amp unswitched socket
MRTPNFO1	1 gang flex outlet
MRTPNSF1	1 gang 13 amp switched fuse spur
MRTPNRFC1	1 gang 13 amp switched fuse cord spur
MRTPNRFC1	1 gang 13 amp switched fuse neon cord spur
MRTPNFSN1	1 gang 13 amp switched fuse neon spur
MRTPNSH1	1 gang shaver socket
MRTPNFSK1	1 gang 13 amp unswitched floor socket
MRTPNFUSK1	1 gang 5 amp unswitched floor socket
MRTPNFSK2	2 gang 13 amp unswitched floor socket
MRTPNFUSK1 2A	1 gang 2 amp unswitched floor socket



Dimmer Switches

MRTPNDSW1	1 gang 400 watt 2 way
MRTPNDSW1 DBL PL	1 gang 400 watt 2 way double plate
MRTPNDSW1 630W	1 gang 630 watt 2 way
MRTPNDSW1 1000W	1 gang 1000 watt 2 way
MRTPNDSW2	2 gang 400 watt 2 way
MRTPNDSW2 DBL PL	2 gang 400 watt 2 way double plate
MRTPNDSW3	3 gang 400 watt 2 way
MRTPNDSW4	4 gang 400 watt 2 way
MRTPNADSW1	1 gang 250 watt architrave



Communication & AV Sockets

MRTPNJM1	1 gang telephone jackline master
MRTPNJM2	2 gang telephone jackline master
MRTPNJS1	1 gang telephone jackline slave
MRTPNJS2	2 gang telephone jackline slave
MRTPNRJ451	1 gang RJ45 cat 5 socket
MRTPNRJ452	2 gang RJ45 cat 5 socket
MRTPNISDN1	1 gang ISDN socket
MRTPNTV1	1 gang television co-axial
MRTPNTV2	2 gang television co-axial
MRTPNTVSAT1	1 gang television and satellite socket
MRTPN SAT1	1 gang satellite socket
MRTPN SAT2	2 gang satellite socket
MRTPN SP1	1 gang speaker socket
MRTPN SKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRTPN TRIPLEX	1 gang TV/FM/SAT



Dolly Switches

MRTPNTSW1	1 gang 20 amp 2 way
MRTPNTSW1 INT	1 gang 20 amp intermediate
MRTPNTSW1 DP	1 gang 20 amp 2 way double plate
MRTPNTSW2	2 gang 20 amp 2 way
MRTPNTSW3	3 gang 20 amp 2 way
MRTPNTSW4	4 gang 20 amp 2 way



Switches

MRTPNCSW1	1 gang 50 amp cooker
MRTPNCSW1 SML	1 gang 45 amp cooker (single plate)
MRTPNCSW1+SSO	1 gang 50 amp cooker with switch socket outlet
MRTPNFAN1	1 gang fan isolator switch
MRTPNPSW1	1 gang ceiling pull



Plates

MRTPNBP1	1 gang single blank plate
MRTPNBP2	2 gang double blank plate
MRTPN EUR1	1 gang single euro plate
MRTPN EUR2	2 gang single euro plate
MRTPN EUR4	4 gang double euro plate
MRTPN EUR8	8 gang double euro plate
MRTPN BRUSH1	1 gang single brush plate 2 slots
MRTPN BRUSH2	2 gang double brush plate 4 slots

Trimless Flat Plate Range





Trimless Flat Plate - polished brass



Rocker Switches

M RTPBRSW1	1 gang 20 amp 2 way
M RTPBRSW1 INT	1 gang 20 amp intermediate
M RTPBRSW1 DP	1 gang 20 amp double pole
M RTPBRSW2	2 gang 20 amp 2 way
M RTPBRSW2 INT	2 gang 20 amp intermediate
M RTPBRSW3	3 gang 20 amp 2 way
M RTPBRSW3 2G PL	3 gang 20 amp 2 way double plate
M RTPBRSW4	4 gang 20 amp 2 way
M RTPBARSW1	1 gang architrave 2 way
M RTPBARSW2	2 gang architrave 2 way



Dimmer Switches

M RTPBDSW1	1 gang 400 watt 2 way
M RTPBDSW1 DBL PL	1 gang 400 watt 2 way double plate
M RTPBDSW1 630W	1 gang 630 watt 2 way
M RTPBDSW1 1000W	1 gang 1000 watt 2 way
M RTPBDSW2	2 gang 400 watt 2 way
M RTPBDSW2 DBL PL	2 gang 400 watt 2 way double plate
M RTPBDSW3	3 gang 400 watt 2 way
M RTPBDSW4	4 gang 400 watt 2 way
M RTPBADSW1	1 gang 250 watt architrave



Dolly Switches

M RTPBTSW1	1 gang 20 amp 2 way
M RTPBTSW1 INT	1 gang 20 amp intermediate
M RTPBTSW1 DP	1 gang 20 amp 2 way double plate
M RTPBTSW2	2 gang 20 amp 2 way
M RTPBTSW3	3 gang 20 amp 2 way
M RTPBTSW4	4 gang 20 amp 2 way



Switches

M RTPBCSW1	1 gang 50 amp cooker
M RTPBCSW1 SML	1 gang 45 amp cooker (single plate)
M RTPBCSW1+SSO	1 gang 50 amp cooker with switch socket outlet
M RTPBFAN1	1 gang fan isolator switch
M RTPBPSW1	1 gang ceiling pull



Sockets

M RTPBSK1	1 gang 13 amp switched
M RTPBSK2	2 gang 13 amp switched
M RTPBUSK1	1 gang 5 amp unswitched socket
M RTPBUSK2	2 gang 5 amp unswitched socket
M RTPBFO1	1 gang flex outlet
M RTPBSF1	1 gang 13 amp switched fuse spur
M RTPBSFC1	1 gang 13 amp switched fuse cord spur
M RTPBUSF1	1 gang 13 amp unswitched fuse spur
M RTPBSFNC1	1 gang 13 amp switched fuse neon cord
M RTPBSFN1	1 gang 13 amp switched fuse neon spur
M RTPBSH1	1 gang shaver socket
M RTPBFSK1	1 gang 13 amp unswitched floor socket
M RTPBFUSK1	1 gang 5 amp unswitched floor socket
M RTPBFSK2	2 gang 13 amp unswitched floor socket
M RTPBFUSK1 2A	1 gang 2 amp unswitched floor socket



Communication & AV Sockets

M RTPBJM1	1 gang telephone jackline master
M RTPBJM2	2 gang telephone jackline master
M RTPBJS1	1 gang telephone jackline slave
M RTPBJS2	2 gang telephone jackline slave
M RTPBRJ451	1 gang RJ45 cat 5 socket
M RTPBRJ452	2 gang RJ45 cat 5 socket
M RTPBISDN1	1 gang ISDN socket
M RTPBTV1	1 gang television co-axial
M RTPBTV2	2 gang television co-axial
M RTPBTVSAT1	1 gang television and satellite socket
M RTPBSAT1	1 gang satellite socket
M RTPBSAT2	2 gang satellite socket
M RTPBSP1	1 gang speaker socket
M RTPBSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
M RTPBTRIPLEX	1 gang TV/FM/SAT



Plates

M RTPBBP1	1 gang single blank plate
M RTPBBP2	2 gang double blank plate
M RTPBEUR1	1 gang single euro plate
M RTPBEUR2	2 gang single euro plate
M RTPBEUR4	4 gang double euro plate
M RTPBEUR8	8 gang double euro plate
M RTPBBRUSH1	1 gang single brush plate 2 slots
M RTPBBRUSH2	2 gang double brush plate 4 slots

Trimless Flat Plate Range





Trimless Georgian - Brass



Rocker Switches

MRTGBRSW1	1 gang 20 amp 2 way
MRTGBRSW1 INT	1 gang 20 amp intermediate
MRTGBRSW2	2 gang 20 amp 2 way
MRTGBRSW3	3 gang 20 amp 2 way
MRTGBRSW4	4 gang 20 amp 2 way



Sockets

MRTGBSK1	1 gang 13 amp switched
MRTGBSK2	2 gang 13 amp switched
MRTGBUSK1	1 gang 5 amp unswitched socket
MRTGBSF1	1 gang 13 amp switched fuse spur
MRTGBSH1	1 gang shaver socket



Dimmer Switches

MRTGBDSW1	1 gang 400 watt 2 way
MRTGBDSW2	2 gang 400 watt 2 way
MRTGBDSW3	3 gang 400 watt 2 way
MRTGBDSW4	4 gang 400 watt 2 way



Communication & AV Sockets

MRTGBJM1	1 gang telephone jackline master
MRTGBJS1	1 gang telephone jackline slave
MRTGBTV1	1 gang television co-axial
MRTGBRJ451	1 gang RJ45 cat 5 socket



Dolly Switches

MRTGBTSW1	1 gang 20 amp 2 way
MRTGBTSW1 INT	1 gang 20amp intermediate
MRTGBTSW2	2 gang 20 amp 2 way
MRTGBTSW3	3 gang 20 amp 2 way
MRTGBTSW4	4 gang 20 amp 2 way



Plates

MRTGBBP1	1 gang single blank plate
MRTGBBP2	2 gang double blank plate
MRTGBEUR1	1 gang single euro plate
MRTGBEUR2	2 gang single euro plate
MRTGBEUR4	4 gang double euro plate

Trimless Rope Edge Range





Classic Flat Plate - primed white



Rocker Switches

MRPWRSW1	1 gang 20 amp 2 way
MRPWRSW1 INT	1 gang 20 amp intermediate
MRPWRSW1 DP	1 gang 20 amp double pole
MRPWRSW2	2 gang 20 amp 2 way
MRPWRSW2 INT	2 gang 20 amp intermediate
MRPWRSW3	3 gang 20 amp 2 way
MRPWRSW4	4 gang 20 amp 2 way
MRPWARSW1	1 gang architrave 2 way
MRPWARSW2	2 gang architrave 2 way



Wall Sockets

MRPWSK1	1 gang 13 amp switched socket outlet
MRPWSK2	2 gang 13 amp switched socket outlet
MRPWUSK1	1 gang 5 amp unswitched socket outlet
MRPWSH1	1 gang shaver socket
MRPWSF1	1 gang 20 amp switched fuse spur
MRPWUSF1	1 gang Fuse Spur 13 amp unswitched
MRPWUSK1	1 gang 5 amp unswitched socket outlet
MRPWUSK1-2A	1 gang 2 amp unswitched socket outlet
MRPWFO1	1 gang flex outlet



Dimmer Switches

MRPWDW1	1 gang 400W 2 way
MRPWDW1 DBL PL	1 gang 400W 2 way double plate
MRPWDW1 1000W/1	1 gang 1000W 2 way
MRPWDW1 INT	1 gang 400W intermediate
MRPWDW1 630W	1 gang 630W 2 way
MRPWDW2	2 gang 630W 2 way
MRPWDW2 DBL PL	2 gang 400W 2 way double plate
MRPWDW3	3 gang 400W 2 way
MRPWDW4	4 gang 400W 2 way
MRPADSW1	1 gang 250W architrave




Floor Sockets

MRPWFSK1	1 gang 13 amp unswitched floor socket
MRPWFSK2	2 gang 13 amp unswitched floor socket
MRPWFSK1	1 gang 5 amp unswitched floor socket




Switches

MRPWFAN1	1 gang fan isolator switch
MRPWCSW1	1 gang 50 amp cooker switch
MRPWCSW1 SML	Cooker Switch 1 gang plate 45 amp cooker switch (single plate)
MRPWPSW1	1 gang ceiling pull switch



Communication & AV Sockets

MRPWJM1	1 gang telephone jackline master
MRPWJS1	1 gang telephone jackline slave
MRPWJM2	2 gang telephone jackline master
MRPWJS2	2 gang telephone jackline slave
MRPWISDN1	1 gang Communications Socket ISDN
MRPWRJ451	1 gang RJ45 cat 5 Socket
MRPWRJ452	2 gang RJ45 cat 5 Socket
MRPWTV1	1 gang television co-axial
MRPWTV1 *NON*	1 gang television co-axial non-isolated
MRPWTV2	2 gang television co-axial
MRPWTV2 *NON*	2 gang TV co-axial and fm non-isolated
MRPWSAT1	1 gang telephone jackline master
MRPWTVSAT1	1 gang television and satellite socket
MRPWTRIPLEX	1 gang television, satellite and FM
MRPWSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRPWSP1	1 gang speaker socket
MRPWSP2	2 gang speaker socket speaker socket



Plates

MRPWBP1	1 gang single blank plate
MRPWBP2	2 gang double blank plate
MRPWEUR1	1 gang single euro plate
MRPWEUR2	2 gang single euro plate
MRPWEUR4	4 gang double euro plate
MRPWEUR8	8 gang double euro plate
MRTPNBRUSH1	1 gang single brush plate 2 slots
MRTPNBRUSH2	2 gang double brush plate 4 slots

The Primed White range can be painted to whatever colour you desire to fit with the decor of the room.

We recommend that 35mm back boxes are used for the entire range





Classic Flat Plate - stainless steel



Rocker Switches

MRSSRSW1	1 gang 20 amp 2 way
MRSSRSW1 DP	1 gang 20 amp double pole
MRSSRSW1 INT	1 gang 20 amp intermediate
MRSSRSW2	2 gang 20 amp 2 way
MRSSRSW2 INT	2 gang 20 amp intermediate
MRSSRSW3	3 gang 20 amp 2 way
MRSSRSW3 INT	3 gang 20 amp intermediate
MRSSRSW4	4 gang 20 amp 2 way
MRSSRSW6	6 gang 20 amp 2 way
MRSSARSW1	1 gang architrave 2 way
MRSSARSW2	2 gang architrave 2 way



Sockets

MRSSSK1	1 gang 13 amp switch socket outlet
MRSSSK2	2 gang 13 amp switch socket outlet
MRSSUSK1	1 gang 5 amp unswitched socket
MRSSUSK1-2A	1 gang 2 amp unswitched socket
MRSSFO1	1 gang flex outlet
MRSSP1	1 gang Light Socket pattress box
MRSSUSF1	1 gang 13 amp unswitched fuse spur
MRSSSFC1	1 gang 13 amp switch fuse cord spur
MRSSSFNC1	1 gang 13 amp switch fuse neon cord spur
MRSSSFN1	1 gang 13 amp switch fuse neon spur
MRSSSF1	1 gang 13 amp switch fuse spur
MRSSFSK1	1 gang 13 amp unswitched
MRSSFSK2	2 gang 13 amp unswitched
MRSSFUSK1	1 gang 5 amp unswitched floor socket
MRSSFUSK1 *2A*	1 gang 2 amp unswitched floor socket
MRSSSH1	1 gang shaver socket



Dimmer Switches

MRSSDSW1	1 gang 400 watt 2 way
MRSSDSW1 INT	1 gang 400 watt intermediate
MRSSDSW1 630W/2G	1 gang 630 watt 2 way double plate
MRSSDSW1 630W	1 gang 630 watt 2 way single plate
MRSSDSW1 1000W	1 gang 1000 watt 2 way double plate
MRSSDSW2	2 gang 400 watt 2 way
MRSSDSW2 DBL PL	2 gang 400 watt double plate
MRSSDSW3	3 gang 400 watt 2 way
MRSSDSW4	4 gang 400 watt 2 way
MRSSDSW6	6 gang 400 watt 2 way
MRSSADSW1	1 gang 250 watt architrave



Communication & AV Sockets

MRSSJM1	1 gang telephone jackline master
MRSSFJM1	1 gang telephone master floor
MRSSFJM2 1G	1 gang telephone master floor (dbl plate)
MRSSJM2	2 gang telephone master
MRSSFJM2	2 gang telephone master floor
MRSSJS1	1 gang telephone slave
MRSSJS2	2 gang telephone slave
MRSSRJ451	1 gang RJ45 cat 5 socket
MRSSFRJ452	2 gang RJ45 cat 5 floor socket
MRSSRJ452	2 gang RJ45 cat 5 socket
MRSSISDN1	1 gang Communications Socket ISDN
MRSSSAT1	1 gang satellite socket
MRSSTV1	1 gang television co-axial
MRSSTV1 *NON*	1 gang television co-axial non-isolated
MRSSTRIPLEX	1 gang television, satellite and FM
MRSSSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRSSTV2	2 gang television co-axial
MRSSTVSAT1	1 gang television and satellite socket
MRSSSP1	1 gang speaker socket



Dolly Switches

MRSSTSW1	1 gang 20 amp 2 way
MRSSTSW1 INT	1 gang 20 amp intermediate
MRSSTSW2	2 gang 20 amp 2 way
MRSSTSW2 INT	2 gang 20 amp intermediate
MRSSTSW3	3 gang 20 amp 2 way
MRSSTSW4	4 gang 20 amp 2 way
MRSSTSW6	6 gang 20 amp 2 way (MK893)



Plates

MRSSBP1	1 gang single blank plate
MRSSBP2	2 gang double blank plate
MRSSEUR1	1 gang single euro plate
MRSSEUR2	2 gang single euro plate
MRSSEUR4	4 gang double euro plate
MRSSEUR8	8 gang double euro plate
MRSSBRUSH1	1 gang single brush plate 2 slots
MRSSBRUSH2	2 gang double brush plate 4 slots



Switches

MRSSCSW1 1G	1 gang plate 45 amp cooker switch
MRSSCSW1 2G	2 gang double plate 50 amp cooker switch
MRSSCSWN1	1 gang 45 amp cooker switch, neon
MRSSCSW1+SSO	1 gang 45 amp cooker switch with outlet
MRSSFAN1	1 gang fan isolator switch
MRSSPSW1	1 gang ceiling pull switch





Classic Flat Plate - polished steel



Rocker Switches

MRPSRSW1	1 gang 20 amp 2 way
MRPSRSW1 INT	1 gang 20 amp intermediate
MRPSRSW1 DP	1 gang 20 amp double pole
MRPSRSW2	2 gang 20 amp 2 way
MRPSRSW2 INT	2 gang 20 amp intermediate
MRPSRSW3	3 gang 20 amp 2 way
MRPSRSW4	4 gang 20 amp 2 way
MRPSARSW1	1 gang 2 way architrave
MRPSARSW2	2 gang 2 way architrave



Dimmer Switches

MRPSDSW1	1 gang 400 watt 2 way
MRPSDSW1 DBL PL	1 gang 1000 watt 2 way double plate
MRPSDSW1 INT	1 gang 400W intermediate
MRPSDSW1 630W	1 gang 630 watt 2 way
MRPSDSW1 1000W	1 gang 1000 watt 2 way
MRPSDSW2	2 gang 400 watt 2 way
MRPSDSW2 DBL PL	2 gang 400 watt 2 way double plate
MRPSDSW3	3 gang 400 watt 2 way
MRPSDSW4	4 gang 400 watt 2 way
MRPSADSW1	1 gang 250 watt architrave



Dolly Switches

MRPSTSW1	1 gang 20 amp 2 way
MRPSTSW1 INT	1 gang 20 amp 2 way intermediate
MRPSTSW1 DP	1 gang 20 amp double pole
MRPSTSW2	2 gang 20 amp 2 way
MRPSTSW3	3 gang 20 amp 2 way
MRPSTSW4	4 gang 20 amp 2 way



Plates

MRPSBP1	1 gang single blank plate
MRPSBP2	2 gang double blank plate
MRPSEUR1	1 gang single euro plate
MRPSEUR2	2 gang single euro plate
MRPSEUR4	4 gang double euro plate
MRPSEUR8	8 gang double euro plate
MRPSBRUSH1	1 gang single brush plate 2 slots
MRPSBRUSH2	2 gang double brush plate 4 slots



Wall Sockets

MRPSSK1	1 gang 13 amp switch socket outlet
MRPSSK2	2 gang 13 amp switch socket outlet
MRPSUSK1	1 gang 5 amp unswitched socket
MRPSUSK1-2A	1 gang 2 amp unswitched socket
MRPSFO1	1 gang flex outlet
MRPSUSF1	1 gang 13 amp unswitched fuse spur
MRPSSFC1	1 gang 13 amp switch fuse cord spur
MRPSSFNC1	1 gang 13 amp switch fuse neon cord spur
MRPSSFN1	1 gang 13 amp switch fuse neon spur
MRPSSF1	1 gang 13 amp switch fuse spur
MRPSSH1	1 gang shaver socket



Floor Sockets

MRPSFSK1	1 gang 13 amp unswitched floor socket
MRPSFUSK1	1 gang 5 amp unswitched floor socket
MRPSFSK2	2 gang 13 amp unswitched floor socket
MRPSFUSK2	2 gang 5 amp unswitched floor socket



Communication & AV Sockets

MRPSJM1	1 gang telephone jackline master
MRPSJS1	1 gang telephone jackline slave
MRPSJM2	2 gang telephone jackline master
MRPSJS2	2 gang telephone jackline slave
MRPSRJ451	1 gang RJ45 cat 5 socket, black insert
MRPSRJ452	2 gang RJ45 cat 5 socket
MRPSISDN1	1 gang ISDN socket
MRPSTV1	1 gang television co-axial
MRPSTV2	2 gang television co-axial
MRPSSAT1	1 gang satellite socket
MRPSTVSAT1	1 gang television and satellite socket
MRPSTRIPLEX	1 gang television, satellite and FM
MRSSSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRPSSP1	1 gang speaker socket



Switches

MRPSCSW1 1G	1 gang 45 amp cooker switch
MRPSCSW1 2G	2 gang 45 amp cooker switch
MRPSCSW1+SSO	1 gang 45 amp cooker switch socket
MRPSPSW1	1 gang ceiling pull switch
MRPSFAN1	1 gang fan isolator switch





Classic Flat Plate - polished brass



Rocker Switches

MRPBRSW1	1 gang 20 amp 2 way
MRPBRSW1 INT	1 gang 20 amp intermediate
MRPBRSW1 DP	1 gang 20 amp double pole
MRPBRSW2	2 gang 20 amp 2 way
MRPBRSW2 INT	2 gang 20 amp intermediate
MRPBRSW3	3 gang 20 amp 2 way
MRPBRSW4	4 gang 20 amp 2 way
MRPBARSW1	1 gang 2 way architrave
MRPBARSW2	2 gang 2 way architrave



Wall Sockets

MRPBSK1	1 gang 13 amp switch socket outlet
MRPBSK2	2 gang 13 amp switch socket outlet
MRPBUSK1	1 gang 5 amp unswitched socket outlet
MRPBUSK1-2A	1 gang 2 amp unswitched socket outlet
MRPBFO1	1 gang flex outlet
MRPBSH1	1 gang shaver socket
MRPBUSF1	1 gang 13 amp unswitched fuse spur
MRPBSFC1	1 gang 13 amp switch fuse cord spur
MRPBSFNC1	1 gang 13 amp switch fuse neon cord spur
MRPBSFN1	1 gang 13 amp switch fuse neon spur
MRPBSF1	1 gang 13 amp switch fuse spur



Dimmer Switches

MRPBDW1	1 gang 400 watt 2 way
MRPBDW1 INT	1 gang 400 watt 2 way intermediate
MRPBDW1 DBL PL	1 gang 400 watt 2 way double plate
MRPBDW1 630W	1 gang 630 watt 2 way
MRPBDW1 1000W	1 gang 1000 watt 2 way
MRPBDW2	2 gang 400 watt 2 way
MRPBDW2 DBL PL	2 gang 400 watt 2 way double plate
MRPBDW3	3 gang 400 watt 2 way
MRPBDW4	4 gang 400 watt 2 way
MRPBADW1	1 gang 250 watt architrave



Floor Sockets

MRPBFSK1	1 gang 13 amp unswitched floor socket
MRPBFSK2	2 gang 13 amp unswitched floor socket
MRPBFUSK1	1 gang 5 amp unswitched floor socket
MRPBFUSK2	2 gang 5 amp unswitched floor socket



Dolly Switches

MRPBTW1 INT	1 gang 20 amp intermediate
MRPBTW1	1 gang 20 amp 2 way
MRPBTW1 DP	1 gang 20 amp double pole
MRPBTW2	2 gang 20 amp 2 way
MRPBTW3	3 gang 20 amp 2 way
MRPBTW4	4 gang 20 amp 2 way



Communication & AV Sockets

MRPBJM1	1 gang telephone jackline master
MRPBISDN1	1 gang ISDN socket
MRPBRJ451	1 gang RJ45 cat 5 socket
MRPBJS1	1 gang telephone jackline secondary
MRPBRJ452	2 gang RJ45 cat 5 socket
MRPBJM2	2 gang telephone jackline master
MRPBJS2	2 gang telephone jackline secondary
MRPBTV1	1 gang television co-axial
MRPBSAT1	1 gang satellite socket
MRPBTVSAT1	1 gang television and satellite socket
MRPBTRIPLEX	1 gang television, satellite and FM socket
MRPBTV2	2 gang television co-axial
MRPBSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRPBSP1	1 gang speaker socket



Plates

MRPBBP1	1 gang single blank plate
MRPBBP2	2 gang double blank plate
MRPBEUR1	1 gang single euro plate
MRPBEUR2	2 gang single euro plate
MRPBEUR4	4 gang double euro plate
MRPBEUR8	8 gang double euro plate
MRPBBRUSH1	1 gang single brush plate 2 slots
MRPBBRUSH2	2 gang double brush plate 4 slots



Switches

MRPBCSW1 1G	1 gang 45 amp cooker switch
MRPBCSW1 2G	2 gang 50 amp cooker switch
MRPBPSW1	1 gang ceiling pull switch
MRPBFAN1	1 gang fan isolator switch
MRPBPSW1	1 gang ceiling pull switch





Classic Flat Plate - satin brass



Rocker Switches

MRSBRSW1	1 gang 20 amp 2 way
MRSBRSW1 INT	1 gang 20 amp intermediate
MRSBRSW1 DP	1 gang 20 amp double pole
MRSBRSW2	2 gang 20 amp 2 way
MRSBRSW2 INT	2 gang 20 amp intermediate
MRSBRSW3	3 gang 20 amp 2 way
MRSBRSW4	4 gang 20 amp 2 way
MRSBASW1	1 gang 2 way architrave
MRSBASW2	2 gang 2 way architrave




Dimmer Switches

MRSBDSW1	1 gang 400 watt 2 way
MRSBDSW1 INT	1 gang 400 watt 2 way intermediate
MRSBDSW1 DBL PL	1 gang 400 watt 2 way double plate
MRSBDSW1 630W	1 gang 630 watt 2 way
MRSBDSW1 1000W	1 gang 1000 watt 2 way
MRSBDSW2	2 gang 400 watt 2 way
MRSBDSW2 DBL PL	2 gang 400 watt 2 way double plate
MRSBDSW3	3 gang 400 watt 2 way
MRSBDSW4	4 gang 400 watt 2 way
MRSBADSW1	1 gang 250 watt architrave



Dolly Switches

MRSBTSW1 INT	1 gang 20 amp intermediate
MRSBTSW1	1 gang 20 amp 2 way
MRSBTSW1 DP	1 gang 20 amp double pole
MRSBTSW2	2 gang 20 amp 2 way
MRSBTSW3	3 gang 20 amp 2 way
MRSBTSW4	4 gang 20 amp 2 way



Plates

MRSBBP1	1 gang single blank plate
MRSBBP2	2 gang double blank plate
MRSBEUR1	1 gang single euro plate
MRSBEUR2	2 gang single euro plate
MRSBEUR4	4 gang double euro plate
MRSBEUR8	8 gang double euro plate
MRSBBRUSH1	1 gang single brush plate 2 slots
MRSBBRUSH2	2 gang double brush plate 4 slots



Wall Sockets

MRSBSK1	1 gang 13 amp switch socket outlet
MRSBSK2	2 gang 13 amp switch socket outlet
MRSBUSK1	1 gang 5 amp unswitched socket outlet
MRSBUSK1-2A	1 gang 2 amp unswitched socket outlet
MRSBFO1	1 gang flex outlet
MRSBSH1	1 gang shaver socket
MRSBUSF1	1 gang 13 amp unswitched fuse spur
MRSBSFC1	1 gang 13 amp switch fuse cord spur
MRSBSFNC1	1 gang 13 amp switch fuse neon cord spur
MRSBSFN1	1 gang 13 amp switch fuse neon spur
MRSBSF1	1 gang 13 amp switch fuse spur



Floor Sockets

MRSBFSK1	1 gang 13 amp unswitched floor socket
MRSBFSK2	2 gang 13 amp unswitched floor socket
MRSBFUSK1	1 gang 5 amp unswitched floor socket
MRSBFUSK2	2 gang 5 amp unswitched floor socket



Communication & AV Sockets

MRSBJM1	1 gang telephone jackline master
MRSBJS1	1 gang telephone jackline secondary
MRSBJM2	2 gang telephone jackline master
MRSBJS2	2 gang telephone jackline secondary
MRSBISDN1	1 gang ISDN socket
MRSBRJ451	1 gang RJ45 cat 5 socket
MRSBRJ452	2 gang RJ45 cat 5 socket
MRSBTV1	1 gang television co-axial
MRSBSAT1	1 gang satellite socket
MRSBTVSAT1	1 gang television and satellite socket
MRSBTRIPLEX	1 gang television, satellite and FM socket
MRSBTV2	2 gang television co-axial
MRSBSKY+	1 gang Sky + 2G TV/FM/SAT2/ Phone
MRSBSP1	1 gang speaker socket



Switches

MRSBCSW1	1 gang 50 amp cooker switch
MRSBCSW1 SML	1 gang 45 amp cooker switch (single plate)
MRSBPWS1	ceiling pull switch
MRSBFAN1	1 gang fan isolator switch
MRSBPWS1	1 gang ceiling pull switch





Classic Flat Plate - clear perspex



Dimmer Switches

MRCPDSW1 1000W	1 gang 1000 watt 2 way
MRCPDSW1	1 gang 400 watt 2 way
MRCPDSW1 630W	1 gang 630 watt 2 way
MRCPDSW2	2 gang 400 watt 2 way
MRCPDSW3	3 gang 250 watt 2 way
MRCPDSW4	4 gang 250 watt 2 way
MRCPADSW1	1 gang 250 watt architrave

Choose from a variety of dimmer modules. Simply add the desired module code (shown below) to the end of your switch code when ordering.



Antique Bronze
BMA



Polished Brass
PB



Satin Steel
SS



Polished Steel
PS



Dolly Switches

MRCPTSW1	1 gang 20 amp 2 way
MRCPTSW1 DP	1 gang 20 amp double pole
MRCPTSW1 INT	1 gang 20 amp intermediate
MRCPTSW2	2 gang 20 amp 2 way
MRCPTSW3	3 gang 20 amp 2 way
MRCPTSW4	4 gang 20 amp 2 way

Choose from a variety of dolly modules. Simply add the desired module code (shown below) to the end of your switch code when ordering.



Antique Bronze
BMA



Polished Brass
PB



Satin Steel
SS



Polished Steel
PS



Rocker Switches

MRCPRSW1	1 gang 20 amp 2 way
MRCPRSW1 INT	1 gang 20 amp intermediate
MRCPRSW1 DP	1 gang 20 amp double pole
MRCPRSW2	2 gang 20 amp 2 way
MRCPRSW2 INT	2 gang 20 amp intermediate
MRCPRSW3	3 gang 20 amp 2 way
MRCPRSW4	4 gang 20 amp 2 way
MRCPARSW1	1 gang 2 way architrave




Wall Sockets

MRCPSK1	1 gang 13 amp switch socket
MRCPSK2	2 gang 13 amp switch socket
MRCPSK2 BRA INS	2 gang 13 amp switch socket brass insert
MRCPSH1	1 gang shaver socket
MRCPUSK1	1 gang 5 amp unswitched socket
MRCPUSK1-2A	1 gang 2 amp unswitched socket
MRCPSF1	1 gang 5 amp unswitched socket
MRCPSF1	1 gang 13 amp switch fuse spur
MRCPUSF1	1 gang 13 amp unswitched fuse spur



Switches

MRCPFAN1	1 gang fan isolator switch
MRCPCSW1	1 gang cooker switch 45A DP



Communication & AV Sockets

MRCPJM1	1 gang telephone jackline master
MRCPJS1	1 gang telephone jackline slave
MRC PJM2	2 gang telephone jackline master
MRCPJS2	2 gang telephone jackline slave
MRCPRJ451	1 gang RJ45 cat 5 socket
MRCPRJ452	2 gang RJ45 cat 5 socket
MRCPISDN1	1 gang ISDN socket
MRCPTV1	1 gang television co-axial
MRCPTV2	2 gang television co-axial
MRCPSAT1	1 gang satellite socket
MRCPSAT2	2 gang satellite socket
MRCPTVSAT1	1 gang television and satellite socket
MRCPTRIPLEX	1 gang television, satellite and FM
MRCPSKY+ 2G	2 gang TV/FM/SAT x 2 and phone socket
MRCPSP1	1 gang speaker socket



Plates

MRCBPB1	1 gang single blank plate
MRCBPB2	2 gang double blank plate
MRCPEUR1	1 gang single euro plate
MRCPEUR2	2 gang single euro plate
MRCPEUR4	4 gang double euro plate
MRCPEUR8	8 gang double euro plate

We recommend that 35mm back boxes are used for the entire range





Classic Flat Plate - antique bronze



Rocker Switches

MRBMARSW1	1 gang 20 amp 2 way
MRBMARSW1 INT	1 gang 20 amp intermediate
MRBMARSW1 DP	1 gang 20 amp double pole
MRBMARSW2	2 gang 20 amp 2 way
MRBMARSW3	3 gang 20 amp 2 way
MRBMARSW4	4 gang 20 amp 2 way
MRPBARSW1	1 gang 2 way architrave
MRPBARSW2	2 gang 2 way architrave



Wall Sockets

MRBMASK1	1 gang 13 amp switch socket
MRBMASK2	2 gang 13 amp switch socket
MRBMAUSK1	1 gang 5 amp unswitched socket
MRBMAUSK1-2A	1 gang 2 amp unswitched floor socket
MRBMAFO1	1 gang flex outlet
MRBMAUSF1	1 gang 13 amp unswitched fuse spur
MRBMASF1	1 gang 13 amp switch fuse cord spur
MRBMASFN1	1 gang 13 amp switch fuse neon spur
MRBMASF1	1 gang 13 amp switch fuse spur
MRBMASH1	1 gang shaver socket



Dimmer Switches

MRBMADSW1	1 gang 400 watt 2 way
MRBMADSW1 1000W	1 gang 1000 watt 2 way double plate
MRBMADSW1 1000	1 gang 1000 watt 2 way single plate
MRBMADSW1 INT	1 gang 400W intermediate
MRBMADSW1 630W	1 gang 630 watt 2 way
MRBMADSW2	2 gang 400 watt 2 way
MRBMADSW2 DBL	2 gang 400 watt 2 way double plate
MRBMADSW3	3 gang 400 watt 2 way
MRBMADSW4	4 gang 400 watt 2 way
MRBMAADSW1	1 gang 250 watt architrave



Floor Sockets

MRBMAFSK1	1 gang 13 amp unswitched floor socket
MRBMAFUSK1	1 gang 5 amp unswitched floor socket
MRBMAFSK2	2 gang 13 amp unswitched floor socket
MRBMAFUSK2	2 gang 5 amp unswitched floor socket



Dolly Switches

MRBMATSW1	1 gang 20 amp 2 way
MRBMATSW1 INT	1 gang 20 amp intermediate
MRBMATSW1 DP	1 gang 20 amp double pole
MRBMATSW2	2 gang 20 amp 2 way
MRBMATSW2 INT	2 gang 20 amp intermediate
MRBMATSW3	3 gang 20 amp 2 way
MRBMATSW4	4 gang 20 amp 2 way



Communication & AV Sockets

MRBMAJM1	1 gang telephone jackline master
MRBMAJS1	1 gang telephone jackline slave
MRBMAJM2	2 gang telephone jackline master
MRBMAJS2	2 gang telephone jackline slave
MRBMAJ451	1 gang RJ45 cat 5 socket
MRBMAJ452	2 gang RJ45 cat 5 socket
MRBMAISDN1	1 gang ISDN socket
MRBMATV1	1 gang television co-axial
MRBMATV2	2 gang television co-axial
MRBMASAT1	1 gang satellite socket
MRBMATVSAT1	1 gang television and satellite socket
MRBMATRIPLEX	1 gang television, satellite and FM
MRBMASP1	1 gang speaker socket



Plates


MRBMABP1	1 gang single blank plate
MRBMABP2	2 gang double blank plate
MRBMAEUR1	1 gang single euro plate
MRBMAEUR2	2 gang single euro plate
MRBMAEUR4	4 gang double euro plate
MRBMAEUR8	8 gang double euro plate
MRBMABRUSH1	1 gang single brush plate 2 slots
MRBMABRUSH2	2 gang double brush plate 4 slots



Switches

MRBMACSW1 1G	1 gang 45 amp cooker switch
MRBMACSW1 2G	2 gang 50 amp cooker switch
MRBMAPSW1	1 gang ceiling pull switch
MRBMAFAN1	1 gang fan isolator switch





Specialist Nautical - polished & satin chrome



Switches

MRNAURSW1	1 gang 20 amp 2 way
MRNAURSW2	2 gang 20 amp 2 way
MRNAURSW3	3 gang 20 amp 2 way
MRNAURSW4	4 gang 20 amp 2 way
MRNAUCSW1 1G	1 gang 45 amp cooker switch



Dimmer Switches

MRNAUDSW1	1 gang 400 watt 2 way
MRNAUDSW2	2 gang 400 watt 2 way
MRNAUDSW3	3 gang 400 watt 2 way
MRNAUDSW4	4 gang 400 watt 2 way



Wall Sockets

MRNAUSK1	1 gang 13 amp switched
MRNAUSK2	2 gang 13 amp switched
MRNAUUSK1	1 gang 5 amp unswitched socket
MRNAUSF1	1 gang 13 amp switched fuse spur



Communication & AV Sockets

MRNAUJM1	1 gang telephone jackline master
MRNAUJS1	1 gang telephone jackline slave
MRNAUTV1	1 gang television co-axial



Plates

MRNAEUR1	1 gang single euro plate
MRNAEUR2	2 gang single euro plate
MRNAEUR4	4 gang double euro plate





Specialist Midas - polished chrome & brass



Switches

MRMIDRSW1	1 gang 20 amp 2 way
MRMIDRSW2	2 gang 20 amp 2 way
MRMIDRSW3	3 gang 20 amp 2 way
MRMIDRSW4	4 gang 20 amp 2 way
MRMIDCSW1 1G	1 gang 45 amp cooker switch



Dimmer Switches

MRMIDDSW1	1 gang 400 watt 2 way
MRMIDDSW2	2 gang 400 watt 2 way
MRMIDDSW3	3 gang 400 watt 2 way
MRMIDDSW4	4 gang 400 watt 2 way



Wall Sockets

MRMIDSK1	1 gang 13 amp switched
MRMIDSK2	2 gang 13 amp switched
MRMIDUSK1	1 gang 5 amp unswitched socket
MRMIDSF1	1 gang 13 amp switched fuse spur



Communication & AV Sockets

MRMIDJM1	1 gang telephone jackline master
MRMIDJS1	1 gang telephone jackline slave
MRMIDTV1	1 gang television co-axial



Plates

MRMIDEUR1	1 gang single euro plate
MRMIDEUR2	2 gang single euro plate
MRMIDEUR4	4 gang double euro plate







Specialist Monaco - polished chrome



Switches

MRMONRSW1	1 gang 20 amp 2 way
MRMONRSW1 INT	1 gang 20 amp intermediate
MRMONRSW2	2 gang 20 amp 2 way
MRMONRSW3	3 gang 20 amp 2 way
MRMONRSW4	4 gang 20 amp 2 way
MRMONCSW1 1G	1 gang 45 amp cooker switch



Sockets

MRMONSK1	1 gang 13 amp switched
MRMONSK2	2 gang 13 amp switched
MRMONUSK1	1 gang 5 amp unswitched socket
MRMONUSF1	1 gang 13 amp unswitched fuse spur
MRMONSH1	1 gang shaver socket



Dimmer Switches

MRMONDSW1	1 gang 400 watt 2 way
MRMONDSW2	2 gang 400 watt 2 way
MRMONDSW3	3 gang 400 watt 2 way
MRMONDSW4	4 gang 400 watt 2 way



Communication & AV Sockets

MRMONJM1	1 gang telephone jackline master
MRMONJS1	1 gang telephone jackline slave
MRMONTV1	1 gang television co-axial
MRMONRJ451	1 gang RJ45 cat 5 socket



Dolly Switches

MRMONTSW1	1 gang 20 amp 2 way
MRMONTSW1 INT	1 gang 20 amp intermediate
MRMONTSW2	2 gang 20 amp 2 way
MRMONTSW3	3 gang 20 amp 2 way
MRMONTSW4	4 gang 20 amp 2 way



Plates

MRMONBP1	1 gang single blank plate
MRMONBP2	2 gang double blank plate
MRMONEUR1	1 gang single euro plate
MRMONEUR2	2 gang single euro plate
MRMONEUR4	4 gang double euro plate





Specialist Screwless - chocolate bronze



Rocker Switches

MRMCBRSW1	1 gang 20 amp 2 way
MRMCBRSW2	2 gang 20 amp 2 way
MRMCBRSW3	3 gang 20 amp 2 way
MRMCBRSW4	4 gang 20 amp 2 way
MRMCBCSW1 1G	1 gang 45 amp cooker switch



Dimmer Switches

MRMCBDSW1	1 gang 400 watt 2 way
MRMCBDSW2	2 gang 400 watt 2 way
MRMCBDSW3	3 gang 400 watt 2 way
MRMCBDSW4	4 gang 400 watt 2 way



Plates

MRMCBEUR1	1 gang single euro plate
MRMCBEUR2	2 gang single euro plate
MRMCBEUR4	4 gang double euro plate



Wall Sockets

MRMCBSK1	1 gang 13 amp switched
MRMCBSK2	2 gang 13 amp switched
MRMCBUSK1	1 gang 5 amp unswitched socket
MRMCBSF1	1 gang 13 amp switched fuse spur




Communication & AV Sockets

MRMCBJM1	1 gang telephone jackline master
MRMCBJS1	1 gang telephone jackline slave
MRMCBTV1	1 gang television co-axial





Aluminium Flat Plate - aluminium



Rocker Switches

MRALRSW1	1 gang 10 amp 2 way
MRALRSW1 INT	1 gang 10 amp intermediate
MRALRSW1 DP	1 gang 20 amp double pole
MRALRSW1 DP	1 gang 20 amp neon double pole
MRALRSW1 RECT	1 gang 10 amp 2 way retractable
MRALRSW2	2 gang 10 amp 2 way
MRALRSW2 INT	2 gang 10 amp intermediate
MRALRSW2 RECT	2 gang 10 amp 2 way retractable
MRALRSW3	3 gang 10 amp 2 way
MRALRSW4	4 gang 10 amp 2 way



Wall Sockets

MRALSK1	1 gang 13 amp switched socket outlet
MRALSK2	2 gang 13 amp switched socket outlet
MRALUSK1-5A	1 gang 5 amp unswitched socket outlet
MRALUSK1-2A	1 gang 2 amp unswitched socket outlet
MRALFO1	1 gang flex outlet
MRALSF1	1 gang 13 amp switched fuse spur
MRALSFN1	1 gang 13 amp switched neon fuse spur
MRALSFNC1	1 gang 13 amp switched fuse neon cord spur
MRALSH1	1 gang shaver outlet



Dimmer Switches

MRALDSW1	1 gang 400 watt 2 way
MRALDSW1 1000W	1 gang 1000 watt 2 way
MRALDSW2	2 gang 400 watt 2 way
MRALDSW3	3 gang 400 watt 2 way
MRALDSW4	4 gang 400 watt 2 way



Floor Sockets

MRALFSK1 OAK	1 gang 13 amp unswitched oak finish
MRALFSK2 OAK	2 gang 13 amp unswitched oak finish



Dolly Switches

MRALTSW1	1 gang 2 way
MRALTSW1 INT	1 gang intermediate
MRALTSW2	2 gang 2 way
MRALTSW2 INT	2 gang intermediate
MRALTSW3	3 gang 2 way
MRALTSW4	4 gang 2 way



Communication & AV Sockets

MRALJM1	1 gang telephone jackline master
MRALJM2	2 gang telephone jackline master
MRALJS1	1 gang telephone jackline slave
MRALJS2	2 gang telephone jackline slave
MRALRJ451	1 gang RJ45 cat 5
MRALRJ452	2 gang RJ45 cat 5
MRALTV1	1 gang isolated television co-axial
MRALTV1 *NON*	1 gang non-isolated television co-axial
MRALTV2 *NON*	2 gang non-isolated television co-axial
MRALTV/FM	2 gang television and FM
MRALSAT1	1 gang satellite
MRALTRIPLEX	1 gang TV/SAT/FM



Switches

MRALCSWN1 1G	1 gang 45 amp neon cooker single plate
MRALCSWN1 2G	2 gang 45 amp neon cooker double plate
MRALCSWN1+SSO	1 gang 45 amp neon cooker with switch socket outlet
MRALFAN1	1 gang fan isolator



Plates

MRALBP1	1 gang single blank plate
MRALBP2	2 gang double blank plate
MRALEUR1	1 gang single euro plate
MRALEUR2	2 gang single euro plate
MRALEUR4	4 gang double euro plate
MRALEUR8	8 gang double euro plate





Aluminium Flat Plate - black



Rocker Switches

MRBKRSW1	1 gang 10 amp 2 way
MRBKRSW1 DP	1 gang 20 amp double pole
MRBKRSW2	2 gang 10 amp 2 way
MRBKRSW2 INT	2 gang intermediate
MRBKRSW3	3 gang 10 amp 2 way
MRBKRSW4	4 gang 10 amp 2 way



Wall Sockets

MRBKSK1	1 gang 13 amp switch socket outlet
MRBKSK2	2 gang 13 amp switch socket outlet
MRBKUSK1 - 2AMP	1 gang 2 amp unswitched socket
MRBKUSK1 - 5AMP	1 gang 5 amp unswitched socket
MRBKSF1	1 gang 13 amp switch fuse spur
MRBKSFN1	1 gang 13 amp switch fuse neon
MRBKSFNC1	1 gang 13 amp switch fuse neon cord spur
MRBKSH1	1 gang shaver socket outlet



Dimmer Switches

MRBKDSW1	1 gang 400 watt 2 way
MRBKDSW1 1000W	1 gang 1000 watt 2 way
MRBKDSW2	2 gang 400 watt 2 way
MRBKDSW3	3 gang 400 watt 2 way
MRBKDSW4	4 gang 400 watt 2 way



Communication & AV Sockets

MRBKJM1	1 gang telephone jackline master
MRBKJS1	1 gang telephone jackline slave
MRBKRJ451	1 gang RJ45 cat 5 socket, black insert
MRBKRJ452	2 gang RJ45 cat 5 socket
MRBKTV1	1 gang television co-axial
MRBKTV1 NON	1 gang television co-axial non-isolated
MRBKTV2 NON	2 gang television co-axial non-isolated
MRBKTV/FM	1 gang television and fm socket



Dolly Switches

MRBKTSW1	1 gang 2 way
MRBKTSW1 INT	1 gang intermediate
MRBKTSW2	2 gang 2 way
MRBKTSW2 INT	2 gang intermediate
MRBKTSW3	3 gang 2 way
MRBKTSW4	4 gang 2 way



Plates

MRBKBP1	1 gang single blank plate
MRBKBP2	2 gang double blank plate
MRBKEUR1	1 gang single euro plate
MRBKEUR2	2 gang single euro plate
MRBKEUR4	4 gang double euro plate
MRBKEUR8	8 gang double euro plate



Switches

MRBKCSWN1 1G	1 gang 45 amp cooker switch with neon
MRBKCSWN1 2G	2 gang 45 amp cooker switch with neon double plate
MRBKCSW1+SSO	1 gang 45 amp cooker switch socket outlet
MRBKFN1	1 gang fan isolator switch





Aluminium Flat Plate - satin white



Rocker Switches

MRWHRSW1	1 gang 10 amp 2 way
MRWHRSW1 INT	1 gang 10 amp intermediate
MRWHRSW1 DP	1 gang 20 amp double pole
MRWHRSW1 DP	1 gang 20 amp neon double pole
MRWHRSW2	2 gang 10 amp 2 way
MRWHRSW2 INT	2 gang 10 amp intermediate
MRWHRSW3	3 gang 10 amp 2 way
MRWHRSW4	4 gang 10 amp 2 way
MRWHRSW6	6 gang 10 amp 2 way



Wall Sockets

MRWHSK1	1 gang 13 amp switched socket outlet
MRWHSK2	2 gang 13 amp switched socket outlet
MRWHUSK1-5A	1 gang 5 amp unswitched socket outlet
MRWHUSK1-2A	1 gang 2 amp unswitched socket outlet
MRWHFO1	1 gang flex outlet
MRWHSF1	1 gang 13 amp switched fuse spur
MRWHUSF1	1 gang 13 amp unswitched fuse spur
MRWHSF1	1 gang 13 amp switched fuse spur
MRWHSFN1	1 gang 13 amp switched neon fuse spur
MRWHSFNC1	1 gang 13 amp switched fuse neon cord spur
MRWHS1	1 gang shaver outlet



Dimmer Switches

MRWHDSW1	1 gang 400 watt 2 way
MRWHDSW1 1000	1 gang 1000 watt 2 way
MRWHDSW2	2 gang 400 watt 2 way
MRWHDSW3	3 gang 400 watt 2 way
MRWHDSW4	4 gang 400 watt 2 way




Communication & AV Sockets

MRWHJM1	1 gang telephone jackline master
MRWHJS1	1 gang telephone jackline slave
MRWHTV1	1 gang isolated television co-axial
MRWHTV1 *NON*	1 gang non-isolated television co-axial
MRWHTV2 *NON*	2 gang non-isolated television co-axial
MRWHTV/FM	2 gang isolated television co-axial and FM
MRWHFM	1 gang FM isolated



Dolly Switches

MRWHSTW1	1 gang 20 amp 2 way
MRWHSTW1 INT	1 gang 20 amp intermediate
MRWHSTW2	2 gang 20 amp 2 way
MRWHSTW2 INT	2 gang 20 amp intermediate
MRWHSTW3	3 gang 20 amp 2 way
MRWHSTW4	4 gang 20 amp 2 way



Plates

MRWHBP1	1 gang single blank plate
MRWHBP2	2 gang double blank plate
MRWHEUR1	1 gang single euro plate
MRWHEUR2	2 gang single euro plate
MRWHEUR4	4 gang double euro plate
MRWHEUR8	8 gang double euro plate



Switches

MRWHCSW1 1G	1 gang 45 amp neon cooker single plate
MRWHCSW1 2G	1 gang 45 amp neon cooker double plate
MRWHCSW1+SSO	1 gang 45 amp neon cooker with switch socket outlet
MRWHFAN1	1 gang fan isolator





Aluminium Flat Plate - pink



Rocker Switches

MRPKRSW1	1 gang 20 amp 2 way
MRPKRSW1 DP	1 gang 20 amp double pole
MRPKRSW1 INT	1 gang 20 amp intermediate
MRPKRSW2	2 gang 20 amp 2 way
MRPKRSW2 INT	2 gang 20 amp intermediate
MRPKRSW3	3 gang 20 amp 2 way
MRPKRSW4	4 gang 20 amp 2 way



Wall Sockets

MRPKSK1	1 gang 13 amp switch socket outlet
MRPKSK2	2 gang 13 amp switch socket outlet
MRPKUSK1 - 2AMP	1 gang 2 amp unswitched socket
MRPKUSK1-5A	1 gang 5 amp unswitched socket
MRPKSF1	1 gang 13 amp switch fuse spur
MRPKUSF1	1 gang 13 amp unswitched fuse spur
MRPKSFN1	1 gang 13 amp switch fuse neon
MRPKSFNC1	1 gang 13 amp switch fuse neon cord spur
MRPKSH1	1 gang shaver socket outlet



Dimmer Switches

MRPKDSW1	1 gang 400 watt 2 way
MRPKDSW2	2 gang 400 watt 2 way
MRPKDSW3	3 gang 400 watt 2 way
MRPKDSW4	4 gang 400 watt 2 way



Communication & AV Sockets

MRPKJM1	1 gang telephone jackline master
MRPKJS1	1 gang telephone jackline slave
MRPKTV1	1 gang television co-axial
MRPKTV1 *NON*	1 gang television co-axial non-isolated
MRPKTV2 *NON*	2 gang television co-axial non-isolated
MRPKTV/FM	1 gang television and fm socket



Dolly Switches

MRPKTSW1	1 gang 2 way
MRPKTSW1 INT	1 gang intermediate
MRPKTSW2	2 gang 2 way
MRPKTSW3	3 gang 2 way
MRPKTSW4	4 gang 2 way



Plates

MRPKBP1	1 gang single blank plate
MRPKBP2	2 gang double blank plate
MRPKEUR1	1 gang single euro plate
MRPKEUR2	2 gang single euro plate
MRPKEUR4	4 gang double euro plate



Switches

MRPKCSWN1 1G	1 gang 45 amp cooker switch with neon
MRPKCSWN1 2G	2 gang 45 amp cooker switch with neon
MRPKCSW1+SSO	1 gang 45 amp cooker switch socket outlet
MRPKFAN1	1 gang fan isolator switch
MRPKDFAN1	1 gang fan isolator dimmer





Aluminium Flat Plate - lime



Rocker Switches

MRLMRSW1	1 gang 20 amp 2 way
MRLMRSW1 DP	1 gang 20 amp double pole
MRLMRSW1 INT	1 gang 20 amp intermediate
MRLMRSW2	2 gang 20 amp 2 way
MRLMRSW2 INT	2 gang 20 amp intermediate
MRLMRSW3	3 gang 20 amp 2 way
MRLMRSW4	4 gang 20 amp 2 way



Wall Sockets

MRLMSK1	1 gang 13 amp switch socket outlet
MRLMSK2	2 gang 13 amp switch socket outlet
MRLMUSK1 - 2AMP	1 gang 2 amp unswitched socket
MRLMUSK1-5A	1 gang 5 amp unswitched socket
MRLMSF1	1 gang 13 amp switch fuse spur
MRLMUSF1	1 gang 13 amp unswitched fuse spur
MRLMSFN1	1 gang 13 amp switch fuse neon
MRLMSFNC1	1 gang 13 amp switch fuse neon cord spur
MRLMSH1	1 gang shaver socket outlet



Dimmer Switches

MRLMDSW1	1 gang 400 watt 2 way
MRLMDSW2	2 gang 400 watt 2 way
MRLMDSW3	3 gang 400 watt 2 way
MRLMDSW4	4 gang 400 watt 2 way



Communication & AV Sockets

MRLMJM1	1 gang telephone jackline master
MRLMJS1	1 gang telephone jackline slave
MRLMTV1	1 gang television co-axial
MRLMTV1 *NON*	1 gang television co-axial non-isolated
MRLMTV2 *NON*	2 gang television co-axial non-isolated
MRLMTV/FM	1 gang television and fm socket



Dolly Switches

MRLMTSW1	1 gang 2 way
MRLMTSW1 INT	1 gang intermediate
MRLMTSW2	2 gang 2 way
MRLMTSW3	3 gang 2 way
MRLMTSW4	4 gang 2 way



Plates

MRLMBP1	1 gang single blank plate
MRLMBP2	2 gang double blank plate
MRLMEUR1	1 gang single euro plate
MRLMEUR2	2 gang single euro plate
MRLMEUR4	4 gang double euro plate



Switches

MRLMCSWN1 1G	1 gang 45 amp cooker switch with neon
MRLMCSWN1 2G	2 gang 45 amp cooker switch with neon
MRLMCSW1+SSO	1 gang 45 amp cooker switch socket outlet
MRLMFAN1	1 gang fan isolator switch
MRLMDFAN1	1 gang fan isolator dimmer





Solowood Flat Plate - oak, zebrano, walnut

Rocker Switches

1 gang 10 amp 2 way
1 gang 20 amp double pole
1 gang 20 amp double pole neon
1 gang intermediate
2 gang 10 amp 2 way
2 gang intermediate
3 gang 10 amp 2 way
4 gang 10 amp 2 way



Oak

OAKRSW1
OAKRSW1 DP
OAKRSWN1 DP
OAKRSW1 INT
OAKRSW2
OAKRSW2 INT
OAKRSW3
OAKRSW4



Zebrano

ZEBRSW1
ZEBRSW1 DP
ZEBRSWN1 DP
ZEBRSW1 INT
ZEBRSW2
ZEBRSW2 INT
ZEBRSW3
ZEBRSW4



Walnut

WALRSW1
WALRSW1 DP
WALRSWN1 DP
WALRSW1 INT
WALRSW2
WALRSW2 INT
WALRSW3
WALRSW4

Dimmer Switches

1 gang 400 watt 2 way
1 gang 1000 watt 2 way single plate
1 gang 1000 watt 2 way double plate
2 gang 250 watt 2 way
2 gang 400 watt 2 way
3 gang 250 watt 2 way
4 gang 250 watt 2 way



Oak

OAKDSW1
OAKDSW1 1000
OAKDSW1 1000W
OAKDSW2 250W
OAKDSW2
OAKDSW3 250W
OAKDSW4 250W



Zebrano

ZEBDSW1
ZEBDSW1 1000
ZEBDSW1 1000W
ZEBDSW2 250W
ZEBDSW2
ZEBDSW3 250W
ZEBDSW4 250W



Walnut

WALDSW1
WALDSW1 1000
WALDSW1 1000W
WALDSW2 250W
WALDSW2
WALDSW3 250W
WALDSW4 250W

Dolly Switches

1 gang 2 way
1 gang intermediate
2 gang 2 way
2 gang intermediate
3 gang 2 way
4 gang 2 way



Oak

OAKTSW1
OAKTSW1 INT
OAKTSW2
OAKTSW2 INT
OAKTSW3
OAKTSW4



Zebrano

ZEBTSW1
ZEBTSW1 INT
ZEBTSW2
ZEBTSW2 INT
ZEBTSW3
ZEBTSW4



Walnut

WALTSW1
WALTSW1 INT
WALTSW2
WALTSW2 INT
WALTSW3
WALTSW4

Switches

1 gang plate 45 amp cooker neon
1 gang plate 45 amp cooker neon
1 gang plate 45 amp cooker switch
with 13A socket outlet
1 gang fan isolator switch
1 gang fan isolator dimmer



Oak

OAKCSWN1
OAKCSWN1 1G
OAKCSW1+SSO

OAKFAN1
OAKDFAN1



Zebrano

ZEBCSWN1
ZEBCSWN1 1G
ZEBCSW1+SSO

ZEBFAN1
ZEBDFAN1



Walnut

WALCSWN1
WALCSWN1 1G
WALCSW1+SSO

WALFAN1
WALDFAN1



Wall Sockets

- 1 gang 13 amp switched socket outlet
- 2 gang 13 amp switched socket outlet
- 1 gang 5 amp unswitched socket outlet
- 1 gang 2 amp unswitched socket outlet
- 1 gang shaver socket
- 1 gang 13 amp switched fuse spur
- 1 gang 13 amp switch fuse neon spur
- 1 gang 13 amp switch fuse neon cord pur
- 1 gang flex outlet
- 1 gang spur 13A unswitched
- 1 gang 13 amp unswitched floor
- 2 gang 13 amp unswitched floor
- 1 gang 5 amp unswitched floor
- 1 gang 2 amp unswitched floor



Oak

- OAKSK1
- OAKSK2
- OAKUSK1
- OAKUSK1-2A
- OAKSH1
- OAKSF1
- OAKSFN1
- OAKSFNC1
- OAKFO1
- OAKUSF1
- OAKFSK1
- OAKFSK2
- OAKFUSK1
- OAKFUSK1-2A



Zebrano

- ZEBSK1
- ZEBSK2
- ZEBUSK1
- ZEBUSK1-2A
- ZEBSH1
- ZEBSF1
- ZEBSFN1
- ZEBSFNC1
- ZEBFO1
- ZEBUSF1
- ZEBFSK1
- ZEBFSK2
- ZEBFUSK1
- ZEBFUSK1-2A



Walnut

- WALSK1
- WALSK2
- WALUSK1
- WALUSK1-2A
- WALSH1
- WALSF1
- WALSFN1
- WALSFNC1
- WALFO1
- WALUSF1
- WALFSK1
- WALFSK2
- WALFUSK1
- WALFUSK1-2A

Communication & AV Sock-

- 1 gang telephone jackline master
- 1 gang telephone jackline slave
- 1 gang RJ45 cat 5 socket
- 2 gang RJ45 cat 5 socket
- 1 gang television co-axial
- 1 gang non-isolated television co-axial
- 2 gang non-isolated television co-axial
- 2 gang television and FM socket
- 1 gang television, FM and satellite socket



Oak

- OAKJM1
- OAKJS1
- OAKRJ451
- OAKRJ452
- OAKTV1
- OAKTV1 *NON*
- OAKTV2 *NON*
- OAKTVFM1
- OAKTRIPLEX



Zebrano

- ZEBJM1
- ZEBJS1
- ZEBRJ451
- ZEBRJ452
- ZEBTV1
- ZEBTV1 *NON*
- ZEBTV2 *NON*
- ZEBTVFM1
- ZEBTRIPLEX



Walnut

- WALJM1
- WALJS1
- WALRJ451
- WALRJ452
- WALTV1
- WALTV1 *NON*
- WALTV2 *NON*
- WALTVFM1
- WALTRIPLEX

Plates

- 1 gang single blank plate
- 2 gang double blank plate
- 1 gang single euro plate
- 2 gang single euro plate
- 4 gang double euro plate



Oak

- OAKBP1
- OAKBP2
- OAKEUR1
- OAKEUR2
- OAKEUR4



Zebrano

- ZEBBP1
- ZEBBP2
- ZEBEUR1
- ZEBEUR2
- ZEBEUR4



Walnut

- WALBP1
- WALBP2
- WALEUR1
- WALEUR2
- WALEUR4



Raised Plate Asbury - ash, light oak, dark oak

Dolly Switches

1 gang 2 way
1 gang intermediate
2 gang 2 way
3 gang 2 way
4 gang 2 way



Ash

BPC01/1.UAW
BPC01/1.INT.UAW
BPC01/2.UAW
BPC01/3.UAW
BPC01/4.UAW



Light Oak

BPB01/1.OB
BPB01/1.INT.OB
BPB01/2.OB
BPB01/3.OB
BPB01/4.OB



Dark Oak

BAB01/1.DKB
BAB01/1.INT.DKB
BAB01/2.DKB
BAB01/3.DKB
BAB01/4.DKB

Requires a single
plate back box



Requires a double
plate back box



Requires a four
plate back box



Wall Sockets

1 gang 13 amp switched socket outlet
2 gang 13 amp switched socket outlet
1 gang 5 amp unswitched socket outlet
1 gang 13 amp switched fuse spur
1 gang shaver socket outlet



Oak

CX06/1.UAW
CX06/2.UAW
CX07/2.UAW
CX05/1.UAW
CX13/1.UAW



Light Oak

CX06/1.OB
CX06/2.OB
CX07/2.OB
CX05/1.OB
CX13/1.OB



Dark Oak

CX06/1.DKB
CX06/2.DKB
CX07/2.DKB
CX05/1.DKB
CX13/1.DKB

Communication/AV Sockets

1 gang telephone jackline master
1 gang telephone jackline slave
1 gang television co-axial



Oak

CX11/1.UAW
CX11/2.UAW
CX09/1.UAW



Light Oak

CX11/1.OB
CX11/2.OB
CX09/1.OB



Dark Oak

CX11/1.DKB
CX11/2.DKB
CX09/1.DKB

Raised Plate Ashbury Range





Elements Flat Plate - copper, magnesium

Rocker Switches

1 gang 10 amp 2 way
1 gang 20 amp double pole
1 gang 20 amp double pole neon
1 gang intermediate
2 gang 10 amp 2 way
3 gang 10 amp 2 way
4 gang 10 amp 2 way



Copper

COPRSW1
COPRSW1 DP
COPRSWN1 DP
COPRSW1 INT
COPRSW2
COPRSW3
COPRSW4



Magnesium

MAGRSW1
MAGRSW1 DP
MAGRSWN1 DP
MAGRSW1 INT
MAGRSW2
MAGRSW3
MAGRSW4


Dimmer Switches

1 gang 400 watt 2 way
1 gang 400 watt 2 way
2 gang 400 watt 2 way
3 gang 400 watt 2 way
4 gang 400 watt 2 way



Copper

COPDSW1
COPDSW1 1000W
COPDSW2
COPDSW3
COPDSW4



Magnesium

MAGDSW1
MAGDSW1 1000W
MAGDSW2
MAGDSW3
MAGDSW4

Dolly Switches

1 gang 2 way
1 gang intermediate
2 gang 2 way
2 gang intermediate
3 gang 2 way
4 gang 2 way



Copper

COPTSW1
COPTSW1 INT
COPTSW2
COPTSW2 INT
COPTSW3
COPTSW4



Magnesium

MAGTSW1
MAGTSW1 INT
MAGTSW2
MAGTSW2 INT
MAGTSW3
MAGTSW4

Switches

1 gang plate 45 amp cooker neon
2 gang plate 45 amp cooker neon
2 gang plate 45 amp cooker switch
with 13A socket outlet
1 gang fan isolator switch



Copper

COPCSWN1
COPCSWN1 1G
COPCSWN1+SSO
COPFAN1



Magnesium

MAGCSWN1
MAGCSWN1 1G
MAGCSWN1+SSO
MAGFAN1

Wall Sockets

- 1 gang 13 amp switch socket outlet
- 2 gang 13 amp switch socket outlet
- 1 gang 5 amp unswitched socket outlet
- 1 gang 2 amp unswitched socket outlet
- 1 gang shaver socket
- 1 gang 13 amp switched fuse spur
- 1 gang 13 amp switch fuse neon spur
- 1 gang 13 amp switch fuse neon cord spur



Copper

- COPRSW1
- COPRSW1 DP
- COPRSWN1 DP
- COPRSW1 INT
- COPRSW2
- COPRSW3
- COPRSW4



Magnesium

- MAGRSW1
- MAGRSW1 DP
- MAGRSWN1 DP
- MAGRSW1 INT
- MAGRSW2
- MAGRSW3
- MAGRSW4

Communication/AV Sockets

- 1 gang telephone jackline master
- 1 gang telephone jackline slave
- 1 gang RJ45 cat 5 socket
- 2 gang RJ45 cat 5 socket
- 1 gang television co-axial
- 1 gang non-isolated television co-axial
- 1 gang television co-axial
- 2 gang non-isolated television co-axial
- 1 gang television, FM and satellite socket
- 1 gang speaker socket



Copper

- COPJM1
- COPJS1
- COPRJ451
- COPRJ452
- COPTV1
- COPTV1 *NON*
- COPTV2
- COPTV2 *NON*
- COPTRIPLEX
- COPSP1 2PIN



Magnesium

- MAGJM1
- MAGJS1
- MAGRJ451
- MAGRJ452
- MAGTV1
- MAGTV1 *NON*
- MAGTV2
- MAGTV2 *NON*
- MAGTRIPLEX
- MAGSP1 2PIN

Plates

- 1 gang single blank plate
- 2 gang double blank plate
- 1 gang single euro plate
- 2 gang single euro plate
- 4 gang double euro plate



Copper

- COPBP1
- COPBP2
- COPEUR1
- COPEUR2
- COPEUR4



Magnesium

- MAGBP1
- MAGBP2
- MAGEUR1
- MAGEUR2
- MAGEUR4



Quarry Raised Plate - black pearl, grey sand

Rocker Switches

1 gang 10 amp 2 way
1 gang 20 amp double pole
1 gang 20 amp double pole neon
1 gang intermediate
2 gang 10 amp 2 way
3 gang 10 amp 2 way
4 gang 10 amp 2 way



Black Pearl

QRBPRSW1
QRBPRSW1 DP
QRBPRSWN1 DP
QRBPRSW1 INT
QRBPRSW2
QRBPRSW3
QRBPRSW4



Grey Sand

QRGSRWS1
QRGSRWS1 DP
QRGSRSWN1 DP
QRGSRWS1 INT
QRGSRWS2
QRGSRWS3
QRGSRWS4



Ivory White

QRIVRSW1
QRIVRSW1 DP
QRIVRSWN1 DP
QRIVRSW1 INT
QRIVRSW2
QRIVRSW3
QRIVRSW4


Dimmer Switches

1 gang 400 watt 2 way
1 gang 1000 watt 2 way single plate
1 gang 1000 watt 2 way double plate
2 gang 400 watt 2 way
3 gang 400 watt 2 way
4 gang 400 watt 2 way



Black Pearl

QRBPDWS1
QRBPDWS1 1000
QRBPDWS1 1000W
QRBPDWS2
QRBPDWS3
QRBPDWS4



Grey Sand

QRGSDWS1
QRGSDWS1 1000
QRGSDWS1 1000W
QRGSDWS2
QRGSDWS3
QRGSDWS4



Ivory White

QRIVDSW1
QRIVDSW1 1000
QRIVDSW1 1000W
QRIVDSW2
QRIVDSW3
QRIVDSW4


Dolly Switches

1 gang 2 way
1 gang intermediate
2 gang 2 way
2 gang intermediate
3 gang 2 way
4 gang 2 way



Black Pearl

QRBPTSW1
QRBPTSW1 INT
QRBPTSW2
QRBPTSW2 INT
QRBPTSW3
QRBPTSW4



Grey Sand

QRGSTSW1
QRGSTSW1 INT
QRGSTSW2
QRGSTSW2 INT
QRGSTSW3
QRGSTSW4




Ivory White

QRIVTSW1
QRIVTSW1 INT
QRIVTSW2
QRIVTSW2 INT
QRIVTSW3
QRIVTSW4

Switches

1 gang plate 45 amp cooker neon large
1 gang plate 45 amp cooker neon small
2 gang plate 45 amp cooker switch with 13A socket outlet
1 gang fan isolator switch



Black Pearl

QRBPCSWN1
QRBPCSWN1 1G
QRBPCSWN1+SSO
QRBPFAN1



Grey Sand

QRGSCSWN1
QRGSCSWN1 1G
QRGSCSWN1+SSO
QRGSFAN1



Ivory White

QRIVCSWN1 2G
QRIVCSWN1 1G
QRIVCSWN1+SSO
QRIVFAN1


Plates

1 gang single blank plate
2 gang double blank plate
1 gang single euro plate
2 gang single euro plate
4 gang double euro plate



Black Pearl

QRBPP1
QRBPP2
QRBPEUR1
QRBPEUR2
QRBPEUR4



Grey Sand

QRGSP1
QRGSP2
QRGSEUR1
QRGSEUR2
QRGSEUR4



Ivory White

QRIVBP1
QRIVBP2
QRIVEUR1
QRIVEUR2
QRIVEUR4



Wall Sockets

1 gang 13 amp switch socket outlet
2 gang 13 amp switch socket outlet
1 gang 5 amp unswitched socket outlet
1 gang 2 amp unswitched socket outlet
1 gang shaver socket
1 gang 13 amp switched fuse spur
1 gang 13 amp switch fuse neon spur
1 gang 13 amp switch fuse neon cord spur
1 gang flex outlet



Black Pearl

QRBPSK1
QRBPSK2
QRBPUK1
QRBPUK1-2A
QRBPSH1
QRBPSF1
QRBPSFN1
QRBPSFNC1
QRBPF01



Grey Sand

QRGSSK1
QRGSSK2
QRGSUK1
QRGSUK1-2A
QRGSSH1
QRGSSF1
QRGSSFN1
QRGSSFNC1
QRGSFO1



Ivory White

QRIVSK1
QRIVSK2
QRIVUK1
QRIVUK1-2A
QRIVSH1
QRIVSF1
QRIVSFN1
QRIVSFNC1
QRIVFO1

Communication/AV Sockets

1 gang telephone jackline master
1 gang telephone jackline slave
1 gang RJ45 cat 5 socket
2 gang RJ45 cat 5 socket
1 gang television co-axial
1 gang non-isolated television co-axial
2 gang television co-axial
2 gang non-isolated television co-axial
1 gang television, FM and satellite socket



Black Pearl

QRBPM1
QRBPS1
QRBPJ451
QRBPJ452
QRBPTV1
QRBPTV1 *NON*
QRBPTV2
QRBPTV2 *NON*
QRBPTRIPLEX



Grey Sand

QRGSJM1
QRGSJS1
QRGSJ451
QRGSJ452
QRGSTV1
QRGSTV1 *NON*
QRGSTV2
QRGSTV2 *NON*
QRGSTRIplex



Ivory White

QRIVJM1
QRIVJS1
QRIVJ451
QRIVJ452
QRIVTV1
QRIVTV1 *NON*
QRIVTV2
QRIVTV2 *NON*
QRIVTRIPLEX

Quarry Finishes


The Quarry Range is available in an assortment of different finishes shown below. Enquire for further information.

Almond Pearl



Code : G08

Grey




Code : S05

Cream




Code : S09

Ivory White




Code : S29

Grey Granite



Code : G17

White Quartz




Code : G04

Blue Sand




Code : G201

Arctic Granite




Code : G34

Green Sand



Code : G20

Venus Green



Code : S204



Accord Raised Plate - polished stainless steel



Rocker Switches

ACPSRSW1	1 gang 10 amp 2 way
ACPSRSW1 INT	1 gang intermediate
ACPSRSW1 DP	1 gang D/P 20amp switch
ACPSRSWN1 DP	1 gang D/P 20amp switch neon
ACPSRSW2	2 gang 10 amp 2 way
ACPSRSW2 INT	2 gang intermediate
ACPSRSW3	3 gang 10 amp 2 way
ACPSRSW4	4 gang 10 amp 2 way



Dimmer Switches

ACPSDSW1	1 gang 400 watt 2 way
ACPSDSW1 1000	1 gang 1000 watt 2 way single plate
ACPSDSW1 1000W	1 gang 1000 watt 2 way double plate
ACPSDSW2 400W	2 gang 400 watt 2 way
ACPSDSW2 250W	2 gang 250 watt 2 way
ACPSDSW3 400W	3 gang 400 watt 2 way
ACPSDSW4 400W	4 gang 400 watt 2 way



Dolly Switches

ACPSTSW1	1 gang 2 way
ACPSTSW1 INT	1 gang intermediate
ACPSTSW2	2 gang 2 way
ACPSTSW2 INT	2 gang intermediate
ACPSTSW3	3 gang 2 way
ACPSTSW4	4 gang 2 way



Switches

ACPSCSWN1	1 gang 45amp double pole cooker switch with neon double vertical plate
ACPSCSWN1 1G	1 gang 45amp D/P Cooker switch with Neon Single Plate
ACPSCSW1+SSO	2 gang 45amp D/P Cooker Switch with 13amp Socket
ACPSDFAN1	1 gang fan isolator dimmer
ACPSFAN1	1 gang fan isolator switch



Wall Sockets

ACPSSK1	1 gang 13amp Switched Socket
ACPSSK2	2 gang 13amp Switched Socket
ACPSUSK1-2A	1 gang 2amp Unswitched Socket
ACPSUSK1	1 gang 5amp Unswitched Socket
ACPSSH1	1 gang Shaver Socket 110/240 Voltage
ACPSF1	1 gang 13amp Switch Fuse Spur
ACPSSFN1	1 gang 13amp Switch Fuse Spur with Neon
ACPSSFNC1	1 gang 13amp Switch Fuse Spur with Neon/Cord
ACPSUSF1	1 gang 13 amp Unswitched Fuse Spur
ACPSFO1	1 gang flex outlet



Communication & AV Sockets

ACPSJM1	1 gang Telephone Master Socket
ACPSJS1	1 gang Telephone Slave Socket
ACPSRJ451	1 gang RJ45 cat 5 socket
ACPSRJ452	2 gang RJ45 cat 5 socket
ACPSTV1	1 gang TV Co-axial
ACPSTV1 *NON*	1 gang TV Co-axial non isolated
ACPSTV2	2 gang TV Co-axial
ACPSTV2 *NON*	2 gang TV Co-axial non isolated
ACPSTRIPLEX	1 gang TV/SAT/FM



Plates

ACPSBP1	1 gang single blank plate
ACPSBP2	2 gang double blank plate
ACPSEUR1	1 gang single euro plate
ACPSEUR2	2 gang single euro plate
ACPSEUR4	4 gang double euro plate

Accord Raised Plate Range





Accord Raised Plate - satin stainless steel



Rocker Switches

ACSSRSW1	1 gang 10 amp 2 way
ACSSRSW1 INT	1 gang intermediate
ACSSRSW1 DP	1 gang D/P 20amp switch
ACSSRSWN1 DP	1 gang D/P 20amp switch neon
ACSSRSW2	2 gang 10 amp 2 way
ACSSRSW2 INT	2 gang intermediate
ACSSRSW3	3 gang 10 amp 2 way
ACSSRSW4	4 gang 10 amp 2 way



Dimmer Switches

ACSSDSW1	1 gang 400 watt 2 way
ACSSDSW1 1000	1 gang 1000 watt 2 way single plate
ACSSDSW1 1000W	1 gang 1000 watt 2 way double plate
ACSSDSW2 400W	2 gang 400 watt 2 way
ACSSDSW2 250W	2 gang 250 watt 2 way
ACSSDSW3 400W	3 gang 400 watt 2 way
ACSSDSW4 400W	4 gang 400 watt 2 way



Dolly Switches

ACSSTSW1	1 gang 2 way
ACSSTSW1 INT	1 gang intermediate
ACSSTSW2	2 gang 2 way
ACSSTSW2 INT	2 gang intermediate
ACSSTSW3	3 gang 2 way
ACSSTSW4	4 gang 2 way



Switches

ACSSCSWN1	1 gang 45amp double pole cooker switch with neon double vertical plate
ACSSCSWN1 1G	1 gang 45amp D/P Cooker switch with Neon Single Plate
ACPSCSW1+SSO	2 gang 45amp D/P Cooker Switch with 13amp Socket
ACSSFAN1	1 gang fan isolator dimmer
ACSSDFAN1	1 gang fan isolator switch



Wall Sockets

ACSSSK1	1 gang 13amp Switched Socket
ACSSSK2	2 gang 13amp Switched Socket
ACSSUSK1-2A	1 gang 2amp Unswitched Socket
ACSSUSK1	1 gang 5amp Unswitched Socket
ACSSSH1	1 gang Shaver Socket 110/240 Voltage
ACSSSF1	1 gang 13amp Switch Fuse Spur
ACSSSFN1	1 gang 13amp Switch Fuse Spur with Neon
ACSSSFCN1	1 gang 13amp Switch Fuse Spur with Neon/Cord
ACSSUSF1	1 gang 13 amp Unswitched Fuse Spur
ACSSF01	1 gang flex outlet



Communication & AV Sockets

ACSSJM1	1 gang Telephone Master Socket
ACSSJS1	1 gang Telephone Slave Socket
ACSSRJ451	1 gang RJ45 cat 5 socket
ACSSRJ452	2 gang RJ45 cat 5 socket
ACSSTV1	1 gang TV Co-axial
ACSSTV1 *NON*	1 gang TV Co-axial non isolated
ACSSTV2	2 gang TV Co-axial
ACSSTV2 *NON*	2 gang TV Co-axial non isolated
ACSSTRIPLEX	1 gang TV/SAT/FM



Plates

ACSSBP1	1 gang single blank plate
ACSSBP2	2 gang double blank plate
ACSSEUR1	1 gang single euro plate
ACSSEUR2	2 gang single euro plate
ACSSEUR4	4 gang double euro plate

Accord Raised Plate Range





Sleek Raised Plate - plastic



Rocker Switches

SWHRSW1 1G 2W	1 gang 10A 2 way
SWHRSW1 INT	1 gang 10A intermediate
SWHRSW2 2G 2W	2 gang 10A 2 way
SWHRSW3 3G 2W	3 gang 10A 2 way
SWHRSW4 4G 2W	4 gang 10A 2 way
SWHARSW1 1G 2W	1 gang Architrave Switch
SWHARSW2 2G 2W	1 gang Architrave Switch

Rocker modules can be removed and changed



Dimmer Switches

SWHDSW1 1G 2W	1 gang 2 way 400W
SWHDSW2 2G 2W	2 gang 2 way 250W
SWHDSW3 3G 2W	3 gang 2 way 250W
SWHDSW4 4G 2W	4 gang 2 way 250W



Switches

SWHCRSW1 1G	1 gang 45amp Cooker Switch Double Pole
SWHCRSW1 2G	2 gang 45amp Cooker Switch Double Pole
SWHCRSW1 1G NEON	1 gang 45amp Cooker Switch Double Pole with Neon
SWHCRSW1 2G NEON	2 gang 45amp Cooker Switch Double Pole with Neon
SWHFAN1 3POLE	1 gang Fan Switch



Euro Plates

SWHEUR1	1 gang single euro plate
SWHEUR2	2 gang single euro plate
SWHEUR4	4 gang double euro plate



Wall Sockets

SWHSK1 13A 1G	1 gang 13amp Switched Socket
SWHUSK1 13A 1G	1 gang 13amp Unswitched Socket
SWHSK2 13A 2G	2 gang 13amp Switched Socket
SWHUSK2 13A 2G	2 gang 13amp Unswitched Socket
SWHUSK1 5A RND1G	1 gang 5amp Unswitched Socket
SWHUSK1 2A RND1G	1 gang 2amp Unswitched Socket
SWHSF1	1 gang 13amp Switch Fuse Spur with Neon
SWHSFNC1	1 gang 13amp Switch Fuse Spur with Neon/Cord
SWHUSF1	1 gang 13 amp Unswitched Fuse Spur
SWHSH1	1 gang Shaver Socket




Communication & AV Sockets

SWHJM1	1 gang Telephone Master Socket
SWHJS1	1 gang Telephone Slave Socket
SWHRJ451	1 gang RJ45 cat 5 socket
SWHRJ452	2 gang RJ45 cat 5 socket
SWHTV1	1 gang Television
SWHTV/FM	1 gang Television, FM
SWHSAT/TV/FM	1 gang Satellite, Television, FM
SWHSAT1	1 gang satellite
SWHSAT2	2 gang satellite



Plates

SWHBP1	1 gang single blank plate
SWHBP2	2 gang double blank plate





Outdoor Range - plastic

The Outdoor Range is manufactured from tough, durable thermoplastic. It is intended for use in an outdoor environment, or one in which the protection provided by the range is required. Rated at IP66, for protection against water and dust. The product will need to be fitted with waterproof cable or conduit entries to maintain the IP rating once installed.

2 Way Rocker Switch



Construction	Thermoplastic
Height	96mm
Width	92mm
Depth	66mm
Operating Temperature	0° to 40° C
Compliance	BS 60669
IP Rating	IP66
Voltage	240V

Code : TGV L01

Outdoor DP Switch



Construction	Thermoplastic
Height	96mm
Width	92mm
Depth	66mm
Operating Temperature	0° to 40° C
Compliance	BS EN 60669 & BS 3676
IP Rating	IP66
Voltage	240V

Code : TGV L05

2 Way Rocker Switch 2 Gang



Construction	Thermoplastic
Height	96mm
Width	92mm
Depth	66mm
Operating Temperature	0° to 40° C
Compliance	BS 60669
IP Rating	IP66
Voltage	240V

Code : TGV L02

Switch Socket - 1 Gang



Code : TGV101

Construction	Thermoplastic
Height	142.5mm
Width	117mm
Depth	75.5mm
Operating Temperature	0°C ~ 40°C
Compliance	BS 1363 & BS EN 60529
IP Rating	IP66
Voltage	240V

Switch Socket - 2 Gang



Code : TGV201

Construction	Thermoplastic
Height	142.5mm
Width	157mm
Depth	75.5mm
Operating Temperature	0°C ~ 40°C
Compliance	BS 1363 & BS 7288
IP Rating	IP66
Voltage	240V



Single Gang 13A - RCD Fused Spur



Code : TGV104

Construction	Thermoplastic
Height	142.5mm
Width	117mm
Depth	75.5mm
Operating Temperature	0°C ~ 40°C
Compliance	BS 1363 & BS EN 60529
IP Rating	IP66
Voltage	240V

Twin Gang 13A - Timer and Socket



Code : TGV203

Construction	Thermoplastic
Height	142.5mm
Width	157mm
Depth	75.5mm
Operating Temperature	0°C ~ 40°C
Compliance	BS 1363 & BS 7288
IP Rating	IP66
Voltage	240V

Single Gang 13A - Fused Spur



Code : TGV103

Construction	Thermoplastic
Height	142.5mm
Width	117mm
Depth	75.5mm
Operating Temperature	0°C ~ 40°C
Compliance	BS1363 & BS7288
IP Rating	IP66
Voltage	240V

Twin Gang 13A - Switched RCD Socket



Code : TGV204

Construction	Thermoplastic
Height	142.5mm
Width	157mm
Depth	75.5mm
Operating Temperature	0°C ~ 40°C
Compliance	BS 1363 & BS 7288
IP Rating	IP66
Voltage	240V

Exterior Time Lag Switch 1 Gang 4000W



Code: TIMELAG EXTL SW 16A

Supply voltage:	230VAC
Weatherproof:	IP66 rating
Maximum load:	16 amps (4000W) of any type of heating load, or resistive, fluorescent or inductive lighting load
Dimensions:	120 x 90 x 60mm

Exterior Time Lag Switch - 1 Gang 1500W



Code: EURO DSSGD EU400W
Slave Code : EURO SSGS EU

Supply voltage:	230VAC
Weatherproof:	IP66 rating
Maximum load:	6 amps (1500W) of any type of heating load, or resistive, fluorescent or inductive lighting load.
Dimensions:	90 x 90 x 60mm



Recessed Floor Boxes

Polished Steel



Floor Boxes

MRPSRFSK1
MRPSRFSK2

1 gang floor box
2 gang floor box

Stainless Steel



Floor Boxes

MRSSRFSK1
MRSSRFSK2

1 gang floor box
2 gang floor box

Polished Brass



Floor Boxes

MRPBRFSK1
MRPBRFSK2

1 gang floor box
2 gang floor box


Antique Bronze



Floor Boxes

MRBMARFSK1
MRBMARFSK2

1 gang floor box
2 gang floor box



Switch Modules

Rocker Switch Modules

					
Classic Flat Plate Rocker Modules	Primed White	Satin Steel	Polished Steel	Polished Brass	Antique Bronze
2 Way Switch	131W WHITE	131SS/W SAT-STL	131PS/B POL-CHR	131PB/W POL-BRA	131BMA BRONZE
DP Switch	132W WHITE	132SS/W SAT-STL	132PS/B POL-CHR	132PB/W POL-BRA	132BMA BRONZE
Intermediate	133W WHITE	133SS/W SAT-STL	133PS/B POL-CHR	133PB/W POL-BRA	133BMA BRONZE
Push to Make	135W WHITE	135SS/W SAT-STL	135PS/B POL-CHR	135PB/W POL-BRA	135BMA BRONZE
2 Way Retractive	137W WHITE	137SS SAT-STEEL	137PS POL-CHROME	137PB/W POL-BRA	137BMA BRONZE

Dolly Switch Modules

				
Flat Plate Dolly Modules	Satin Steel	Polished Steel	Polished Brass	Antique Bronze
2 Way Switch	91SS	91PS	91PB	91BMA
DP Switch	92SS	92PS	92PB	92BMA
Intermediate	93SS	93PS	93PB	93BMA

Dimmer Switch Modules

	
Dimmer Modules	
60/250W Push on/off Module	DPD250W
60/400W Push on/off Module	DPD400W
60/1000W Push on/off Module	IDIMP1000
1-10V High Frequency Dimmer Module	DPD10VDC MODULE
Inductive/Resistive Load 1-2 Way Switching Module	DPS1500W

Dimmer Switch Modules

	
Push Button Modules	
Polished Chrome Push button Module	95SBC POL-CHROME
Satin Chrome Push button Module	95SC SAT-CHROME
Polished Nickel Push button Module	95SBN POL-NICKEL
Satin Nickel Push button Module	95SN SAT-NICKEL
Polished Brass Push button Module	95SBN POL- BRASS
Bronze Push button Module	95SAB BMA

					
Flat Plate Dimmer Switch Caps	Primed White	Satin Steel	Polished Steel	Polished Brass	Antique Bronze
6mm Dimmer Cap	PWCAP *6MM*	SSCAP *6MM*	PSCAP *6MM*	PBCAP *6MM*	BMACAP *6MM*
					
6mm Dimmer Cap	Sat Nickel	Polished Nickel			
4mm Dimmer Cap	SNCAP *6MM*	PNCAP *6MM*			
	SNCAP *4MM*	PNCAP *4MM*			



Special Bespoke Switches

Specially manufactured bespoke switches are available for less general requirements. Switches can be designed to give maximum convenience and usage in a space. We also offer the option of having your switches engraved.

For more information email : info@mr-resistor.co.uk





Back Boxes

Switch Plates are available for the following size backboxes. We can make custom back boxes for any size plate.

Architrave

72mm x 27mm x 25mm



Code : MK3921

6 gang plate


133mm x 133mm x 40mm



Code : MK893

8 gang plate

133mm x 133mm x 40mm



Code : MK893

9 gang plate

194mm x 133mm x 40mm



Code : MK895

12 gang plate


194mm x 133mm x 40mm



Code : MK895

18 gang plate

194mm x 194mm x 56mm



Code : MK898

24 gang plate

254mm x 194mm x 56mm



Code : MK900



Surfaced Pattress Boxes


Polished Steel



Pattress Boxes

MRPSP1 1 gang pattress box
MRPSP2 2 gang pattress box

Stainless Steel



Pattress Boxes

MRSSP1 1 gang floor box
MRSSP2 2 gang floor box

Polished Brass



Pattress Boxes

MRPBP1 1 gang floor box
MRPBP2 2 gang floor box

Antique Bronze



Pattress Boxes

MRBMAP1 1 gang floor box
MRBMAP2 2 gang floor box

Euro Plates



1 gang single euro plate




4 gang double euro plate



2 gang single euro plate



Euro Plate with Modules



8 gang double euro plate



Double Brush Plate



Single Brush Plate

You no longer have to install audio visual switches and sockets that are built into a standard inflexible plate. You can now interchange your inserts within a quality Euro Plate. The modules simply click into place in any order you choose to suit your needs.

From Satellite and TV outlets to phone and speaker sockets, AV Modules are the flexible answer to audio visual electrical accessories. All modules are made to the standard Euro grid configuration based on one aperture modules of 25mm x 50mm.

Trimless Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate
8 gang double euro plate
single brush plate
double brush plate



Antique Silver

MRTASEUR1
MRTASEUR2
MRTASEUR4
MRTASEUR8
MRTASBRUSH1
MRTASBRUSH2



Satin Nickel

MRTSNEUR1
MRTSNEUR2
MRTSNEUR4
MRTSNEUR8
MRTSNBRUSH1
MRTSNBRUSH2



Polished Nickel

M RTPNEUR1
M RTPNEUR2
M RTPNEUR4
M RTPNEUR8
M RTPNBRUSH1
M RTPNBRUSH2



Polished Brass

M RTPBEUR1
M RTPBEUR2
M RTPBEUR4
M RTPBEUR8
M RTPBBRUSH1
M RTPBBRUSH2

Trimless Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate



Georgian Brass

MRTGBEUR1
MRTGBEUR2
MRTGBEUR4

Euro Plates

Classic Flat Plate Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate
8 gang double euro plate
single brush plate
double brush plate



Primed White

MRPWEUR1
MRPWEUR2
MRPWEUR4
MRPWEUR8
MRPWBRUSH1
MRPWBRUSH2



Satin Steel

MRSSEUR1
MRSSEUR2
MRSSEUR4
MRSSEUR8
MRSSBRUSH1
MRSSBRUSH2



Polished Steel

MRPSEUR1
MRPSEUR2
MRPSEUR4
MRPSEUR8
MRPSBRUSH1
MRPSBRUSH2



Polished Brass

MRPWEUR1
MRPWEUR2
MRPWEUR4
MRPWEUR8
MRPWBRUSH1
MRPWBRUSH2

Classic Flat Plate Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate
8 gang double euro plate
single brush plate
double brush plate




Satin Brass

MRSBEUR1
MRSBEUR2
MRSBEUR4
MRSBEUR8
MRSBBRUSH1
MRSBBRUSH2



Clear Perspex

MRCPEUR1
MRCPEUR2
MRCPEUR4
MRCPEUR8
MRCPBRUSH1
MRCPBRUSH2



Antique Bronze

MRBMAEUR1
MRBMAEUR2
MRBMAEUR4
MRBMAEUR8
MRBMABRUSH1
MRBMABRUSH2

Aluminium Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate
8 gang double euro plate



Satin White

MRWHEUR1
MRWHEUR2
MRWHEUR4
MRWHEUR8



Aluminium

MRALEUR1
MRALEUR2
MRALEUR4
MRALEUR8



Black

MRPSEUR1
MRPSEUR2
MRPSEUR4
MRPSEUR8



Pink

MRPKEUR1
MRPKEUR2
MRPKEUR4



Lime

MRLMEUR1
MRLMEUR2
MRLMEUR4

Specialist Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate



Nautical

MRNAEUR1
MRNAEUR2
MRNAEUR4



Midas

MRMIDEUR1
MRMIDEUR2
MRMIDEUR4



Monaco

MRMONEUR1
MRMONEUR2
MRMONEUR4



Screwless

MRMCBEUR1
MRMCBEUR2
MRMCBEUR4

Wood

Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate
8 gang double euro plate



Oak

OAKEUR1
OAKEUR2
OAKEUR4



Walnut

WALEUR1
WALEUR2
WALEUR4



Zebrano

ZEBEUR1
ZEBEUR2
ZEBEUR4

Element

Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate



Copper

COPEUR1
COPEUR2
COPEUR4



Magnesium

MAGEUR1
MAGEUR2
MAGEUR4



Black Pearl

QRBPEUR1
QRBPEUR2
QRBPEUR4



Grey Sand

QRGSEUR1
QRGSEUR2
QRGSEUR4

Quarry

Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate



Satin Steel

ACSSEUR1
ACSSEUR2
ACSSEUR4



Polished Steel

ACPSEUR1
ACPSEUR2
ACPSEUR4

Accord

Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate



Plastic

SWHEUR1
SWHEUR2
SWHEUR4

Sleek

Euro Plates

1 gang single euro plate
2 gang single euro plate
4 gang double euro plate

Euro Modules

Switch Modules

1 GANG ROCKER MODULE 16A 2 WAY



white, white insert code: CM202 WHT
black, black insert code : CM202 BLK



polished brass, white insert code : CM202DK PBW
polished brass, black insert code : CM202DK PBB



polished steel, white insert code : CM202DK PSW
polished steel, black insert code : CM202DK PSB



satin steel, white insert code : CM202DK SSW
satin steel, black insert code : CM202DK SSB

1 GANG ROCKER MODULE 16A DOUBLE POLE



white, white insert code: CM204 WHT
black, black insert code : CM204 BLK



polished brass, white insert code : CM204DK PBW
polished brass, black insert code : CM204DK PBB



polished steel, white insert code : CM204DK PSW
polished steel, black insert code : CM204DK PSB



satin steel, white insert code : CM204DK SSW
satin steel, black insert code : CM204DK SSB

1 GANG ROCKER MODULE 16A INTERMEDIATE



white, white insert code: CM203 WHT
black, black insert code : CM203 BLK



polished brass, white trim : CM203DK PBW
polished brass, black trim : CM203DK PBB



polished steel, white trim : CM203DK PSW
polished steel, black trim : CM203DK PSB



satin steel, white trim : CM203DK SSW
satin steel, black trim : CM203DK SSB

SECURITY SWITCH MODULES DP WITH KEY



white, white insert code: CM205 WHT
black, black insert code : CM205 BLK



neon, white insert code: CM206 WHT NEON
neon, black insert code : CM206 BLK NEON

Sockets



13A UNSWITCHED MODULE

white, code : CM317 WHT
black, code : CM317 BLK



5A UNSWITCHED MODULE

white, code : CM316 WHT
black, code : CM316 BLK



16A GERMAN UNSWITCHED MODULE

white, code : CM315 WHT
black, code : CM315 BLK



FRENCH/BELGIUM UNSWITCHED MODULE

white, code : CM314 WHT
black, code : CM314 BLK



15A USA UNSWITCHED MODULE

white, code : CM313 WHT
black, code : CM313 BLK



16A 2 PIN UNSWITCHED MODULE

white, code : CM210 WHT
black, code : CM210 BLK



USB MODULE

white, code: EURO1USB WHITE
black, code : EURO1USB BLACK

Communication Modules



RJ45 CAT 5E MODULE

white, code : CM014 WHT
black, code : CM014 BLK



RJ45 CAT 6 MODULE

white, code : CM016 WHT
black, code : CM016 BLK



RJ11 MODULE

white, code : CM037 WHT
black, code : CM037 BLK



MASTER VOICE MODULE

white, code : CM111 WHT
black, code : CM111 BLK



SECONDARY VOICE MODULE

white, code : CM112 WHT
black, code : CM112 BLK

Euro Modules

Audio/Visual Modules



TV OUTLET MODULE (FEMALE)
white, code : CM009 WHT
black, code : CM009 BLK



TV OUTLET MODULE (MALE)
white, code : MRAV009E WHT
black, code : MRAV009E BLK



TV OUTLET, FEMALE, SCREENED RETURN
white, code : CM011 WHT
black, code : CM011 BLK



TV OUTLET, FEMALE ISOLATED
white, code : CM010 WHT
black, code : CM010 BLK



SATELLITE TV OUTLET MODULE
white, code : CM046 WHT
black, code : CM046 BLK



DIPLEX MODULE (FM DAB/TV)
white, code : CM032 WHT
black, code : CM032 BLK



TRIPLEX (FM DAB/SAT/TV) MODULE
white, code : CM011 WHT
black, code : CM011 BLK



QUADPLEX (2 SAT/TV/FM DAB) MODULE
white, code : CM034 WHT
black, code : CM034 BLK



DOUBLE SATELLITE MODULE (SKY+)
white, code : CM133 WHT
black, code : CM133 BLK



BNC (FEMALE) MODULE
white, code : MRAVR014 WHT
black, code : MRAVR014 BLK



PHONO (FEMALE) MODULE (RCA)
white, code : MRAV015 WHT
black, code : MRAV015 BLK



SPEAKER MODULE, 2 BINDING POSTS
white, code : CM002 WHT
black, code : CM002 BLK



SPEAKER MODULE, 4 POSTS
white, code : CM004 WHT
black, code : CM004 BLK



2 RCA (PHONO)
white, code : MRAVR032 WH
black, code : MRAVR032 BLK



3 RCA (PHONO)
white, code : MRR033 WHT
black, code : MRR033 BLK



HDMI MODULE (TAILED)
white, code : MRAVR030 WHT
black, code : MRAVR030 BLK

Blank Modules



HALF BLANK
white, code : CM001 WHT
black, code : CM001 BLK



SINGLE BLANK
white, code : CM101 WHT
black, code : CM101 BLK



DOUBLE BLANK
white, code : CM201 WHT
black, code : CM201 BLK


Brush Insert



SINGLE BRUSH
black, code : CMBR1B



DOUBLE BRUSH
black, code : CMBR2B



QUADRUPLE BLANK
black, code : CMBR4B

Euro Modules

PIR Occupancy Switch Modules

These modules are suitable for mounting onto Euro plates and fit into a 35mm deep wall box. They are also suitable for building into luminaires (see page 64 for fixing bezel). They require a neutral wire.

5m detection - concealed adjustment spindles



Detection angle:	100°
Time lag range:	10 seconds to 40 minutes in 9 steps
Photocell range:	15 to 1000 lux, and inactive
Loading:	Up to 6 amps (1500W) of resistive, fluorescent or inductive lighting loads, or up to 1 amp (250W) of fans.
Dimensions:	50 x 25 x 38mm, minimum wall box depth of 35mm

Code: EURO GREUWPIR5X

10m detection - concealed adjustment spindles



Detection zone:	360°
Detection angle:	100°
Time lag range:	10 seconds to 40 minutes in 9 steps
Photocell range:	15 to 1000 lux, and inactive
Loading:	Up to 6 amps (1500W) of resistive, fluorescent or inductive lighting loads, or up to 1 amp (250W) of fans.
Dimensions:	50 x 25 x 38mm, minimum wall box depth of 35mm

Code: EURO GREUWPIR10X

Dimmers

These dimmers can be used to dim lights from several locations. They are suitable for dimming resistive lamps, dimmable transformer low voltage lamps, most directly dimmable compact fluorescent loads and directly dimmable LED lamps.

Soft start dimmers

For loading of Grid dimmers on multi-gang plates the following limits also apply:



2 gang plates:	Maximum for total plate – 630W
3 or 4 gang plates:	Maximum for total plate – 1000W
6, 8, 9 or 12 gang plates:	Maximum per row – 1000W
18 or 24 gang plates:	Maximum per row – 1200W

Dimensions:	50 x 25 x 38mm, minimum wall box depth of 35mm
-------------	--

Code: EURO DSSGDEU400W

Slave Code : EURO SSGSEU

Manual high frequency dimmers

Suitable for dimmable ballasts with 1-10VDC input. Push on, push off, hold to dim.

Versions to suit the Euro plates.

They may be placed in any position on the appropriate grid or plate.

They can also be operated by additional mains rated, normally open push buttons.



Loading:	Total load of ballast, lamps plus other load not more than 6 amps including fluorescent. Can control up to 20mA, eg. 20 ballasts at 1mA. Varies according to make and model of ballasts. When controlling LED drivers a load capacitor (order code CAPLOAD) may be required to augment the load
----------	---

Dimensions:	50 x 25 x 38mm. Minimum wall box depth 35mm
-------------	---

Code: EURO DSSGDEU10V

Time Lag Switches

These electronic time lag switches are designed to switch lights, or other loads ON, and then to switch them OFF automatically after the set time lag has elapsed. Their energy saving benefits make these switches ideal for use in stairwells, store rooms and in many other applications.

Grid time lag switches - 2 wire versions



Time lag: 1 to 120 minutes (adjustable)
Maximum load: 6 amps (1500W) of resistive, fluorescent or inductive lighting loads, or up to 1 amp (250W) of fans
Minimum load: 2W of resistive. A load capacitor (order code CAPLOAD) can be supplied to augment small or non-resistive loads

Dimensions: Module for Eurodata plates: 50 x 25 x 38mm.
Minimum wall box depth 35mm

Code: EURO GRTLEU

Slave Code : EURO GRTLEU1LM

Grid Modules

Slide Grid Dimmer

This module can be used to custom make your own switch/dimmer as the module is manufactured to fit in common available wall plates and back boxes. It can also be used as a direct replacement for faulty or broken modules in existing switch/dimmers. This module includes adaptor plates for the MK Gridswitch system, Delta System, Crabtree System and the MEM System.



Slide Grid Dimmer - 40-250W

Code: 6SGD250



Slide Grid Dimmer - 40-250W

Code: 6SGD400



Slide Grid Controller - 1-10V

Code: 6GC110V



Slide Grid Dimmer - 60-630W

Code: 6SGD630



Pop-Up Socket - PowerPort

The Pop-Up Socket - PowerPort features 3 x UK plug sockets and 2 x USB power sockets in an aluminium housing that neatly slots away in its fully retracted position.

The Pop-Up Socket can be easily fitted into work surfaces by cutting a 102-105mm diameter hole. A minimum of 350mm clearance is required beneath the worktop.

Once installed simply press for automatic pop up. No wiring is necessary as a 1.5m plugged cable is provided. Ideal for kitchen surfaces and home offices.


Code: MRPOPSK3+2USB



PIR Sensor Switches

The PIR Flush Mounted Occupancy Switch is a passive infrared switch that will turn on/off any type of connected load, including electronic control gear. Bring lights on only when area is occupied, then automatically turn off after an adjustable set time after the movement was detected.

PIR 360° Occupancy Switch - 1500W



White Code: MR6PIRW01/WH MET
 Chrome Code: MR6PIRC01/CHR
 Stainless Steel Code: MR6PIR01/SS
 Brass Code: MR6PIRB01/BR

PIR Occupancy Switch - 0-6A



White Code: CEFLPIR SEALED

PIR Occupancy Switch with 1-10V
 Daylight Linked Dimming - 1500W



White Code: CEFL PIRDD 10VDC

Dusk to Dawn PIR Light Controller - 3000W



White Code: NSLDD1000

Cupboard & Wardrobe Sensor Switch

PIR Movement Sensor Switch - 250W



Silver Code: LLSENTPIRTIM SIL

PIR Movement Sensor Switch - 500W



Silver Code: 12401230101

Table Lamp Switches & Dimmers

Dimmers

Slide Dimmer 240V

The Slide Dimmer 240V is an in-line slide dimmer which can be used in conjunction with your incandescent or halogen floor/table lamps. The dimmer can be controlled by either hand or foot.

Construction	Plastic
Height	39mm
Width	71mm
Length	115mm
Minimum Wattage	60W
Maximum Wattage	300W
Voltage	240V



Brass Code : RT81 BRASS



Black Code : RT81 BLACK



White Code : RT81 WHITE

Rotary Dimmer Switch 240V

The FlexiDimm is an in line dimmer for use with halogen and incandescent table and floor lamps. It is small, light, discrete, easy to use and easy to connect. It is regulated by a built in rotative potentiometer. This dimmer is not a switch and will still be a live circuit even when the light source is dimmed down to 0%.

Construction	Plastic
Height	27mm
Width	28mm
Length	92mm
Minimum Wattage	40W
Maximum Wattage	160W
Voltage	240V



Black Code:FLEXIDIMM BLACK



White Code:FLEXIDIMM WHITE



Clear Code:FLEXIDIMM CLEAR

Switches

A 3 core in-line switch to be used in conjunction with unswitched fittings.

Construction	Plastic
Amperage	2A
Depth	19mm
Length	62mm
Width	25mm
Core	3



White Code: 478 WHITE



White Code: 478 BLACK

Door Switches - 2A Push to Break

Door Switches enable you to turn a light on and off in a cupboard or room. When the door is closed on the switch the light would be turned off, as soon as the door is opened and the switch is released the light will turn on



Chrome Code : 141WB CHROME



Brass Code : 141WB BRASS

Construction	Polished Steel
Depth	28mm
Height	78mm
Width	24mm
Amperage	2A
Voltage	240V



Chrome Code : 140LPC CHROME



Brass Code : 140LPB BRASS

Construction	Plated Steel
Depth	40mm
Height	80mm
Width	25mm
Amperage	2A
Voltage	240V



White Code :143 WHITE




Black Code : 143 BLACK

Construction	Plastic
Depth	50mm
Height	42mm
Width	16mm
Amperage	2A
Voltage	240V

Door Switch Back Box Code :140BOX

Special Cable


3 Core Cloth Covered Cable 0.75mm



3 Core Braided Cable 0.75mm



Clear Cable 0.75mm



3 Core Clear Silver 0.75mm



3 Core Curly Cable 0.75mm - 0.5m-2m



Lamp holders & Accessories

Switched Lamp Holder - 13mm BC / B22
Height - 58mm, Diameter - 32mm

Chrome



Code : A38C

Black Nickel



Code : A38BN

Antique Brass



Code : A38AB

Ceramic



Code : PIGGY

Unswitched Lamp Holder - 13mm BC / B22
Height - 38mm, Diameter - 32mm

Chrome



Code : 05139 CHROME

Bronze



Code : 05141 BRONZE

Antique Brass



Code : 05142 ANT-BRASS

Brass



Code : 05137 BRASS

Antique Brass



Code : 05140 NICKEL

Reducer

Height - 15mm, Diameter - 15mm

Antique Brass



Code : 05230 ANT-BRASS

Brass



Code : 05229 BRASS

Chrome



Code : 05231 CHROME

Carbon Filament Lamps

GLS Rustika
BC / B22 60W



Code : GLS CARBON BC

Multiple Filament Rustika
BC / B22 60W



Code : SQUIRREL B22 CLR

Cord Grip

White



Code : 5706 WHITE

Black



Code : 5706 BLACK

Lamp holders & Accessories

Dome Ceiling Roses

Height - 30mm, Diameter - 85mm

Chrome



Code : 104 CHROME

Satin Steel



Code : 104 SATIN STEEL

White



Code : 104

Brass



Code : 104 BRASS

Traditional Ceiling Roses

Height - 50mm, Diameter - 84mm

Plain Ceiling Rose



Code : ROSE CEIL PLAIN

Fluted Ceiling Rose



Code : ROSE CEIL FLUTED

Porcelain Ceiling Rose

Height - 75mm, Diameter - 105mm

Porcelain Ceiling Rose



Code : ROSE PORCELIAN

Ceiling Hook Plates

Height - 55mm, Diameter - 66mm, Holds - 5kg

Chrome



Code :
HOOK PLATE CHROM

Bronze



Code :
HOOK PLATE BRZ

Antique Brass



Code :
HOOK PLATE ANTIQ

Brass



Code :
HOOK PLATE BRASS

White



Code :
HOOK PLATE WHITE

Silver



Code :
HOOK PLATE STEEL

Black



Code :
HOOK PLATE BLACK

Ceiling Hook Plates

Height - 42mm, Diameter - 72mm, Holds - 5kg

Chrome

Brass



Code :
05911 3-HOOK CHR

Code :
05070 3-HOOK BRA

Detachable Ceiling Hooks

Height - 75mm, Diameter - 105mm, Holds - 5kg

Chrome

White

Brass

Black



Code : MB11C

Code : MB11E

Code : MB11A

Code : MB11D

Ceiling Chain

1m Silver
Link - 30mm



Code : 326HG GALV

1m Bronze
Link - 40mm



Code : 61151 RUSTIC

10m Hot Dip Welded
Link - 30mm



Code : 326HG GALV X10

1m Brass
Link - 40mm



Code : 61151 FANCY

1m Brass
Link - 40mm



Code : 61151 BRASS

