


Parts needed to mount the TEKNIK-ZM extrusion



Extrusion (A)



End cap (B)


Tools needed for mounting:

- drill
- screwdriver


NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure. More mounting procedures and related accessories can be found at www.klusdesign.com

1. Drill holes in the extrusion (A).



2. Insert the end cap (B) into the extrusion (A), and then mount the extrusion with screws



3. Slide the clips into the LED fixture, then connect power and insert the LED fixture into the extrusion (A). The number of clips should be: 4 for 3.28" long extrusions, 9 for 6.56" long extrusions and 14 for 9.84" long extrusions. First and last clip should be placed 1.9"-2.7" from the end of the extrusion.

ATTENTION: Extrusions can be connected with ZM connectors.

